Product Specification

Model	DiTT
Package Dimension	180*115*50 MM
Neck Circumference	80CM*2 MM
Receiver's Casing	IP68 waterproof
Remote's Casing	Non-waterproof
Remote/Receiver's battery	3.7V/300mAh LIP
Charging Voltage	TYPE-C 5V
Remote/Receiver Charging Time	2 hours
Charging Port	TYPE-C
Wireless Power	10mW
Operating Environment	0~45℃
Remote/Receiver Standby Time	Remote: 120 days Receiver: 45 days
Frequance	433MHz

SLOPEHILL

Training Collar Dog

User Manual
Model: DiTT



support@slopehill.com
+1-732-762-2943

support@slopehill.com +1-732-762-2943 Made in China FCC ID: 2A3TP-DiTT

WARNING
1. Before using the product, please read the user manual and any safety information completely to avoid injury caused by inappropriate usage!
2. Please follow the instructions and safety directions in the manual. We are not responsible for damages or injuries caused by improper usage!
3. Please check the user manual carefully for failure solving.

Terms of Use and Limitation of Liability

1. By using this product, you agree to all of its terms and conditions.
2. This product is a high-quality professional dog training equipment that is designed to correct dog's bad behavior. It is not a toy and should be kept away from children and pets. If you have any doubts about the suitability of a product for your companion dog, please consult a professional handler or contact us.
3. This product is intended for professional dog training purposes only and should not be used for any other reason. Please do not use this product in violation of any local laws.
4. We disclaim all liability for direct or indirect damages resulting from the misuse of this product. All risks associated with its usage will be borne by the user.
5. We retain the right to make changes to the terms, conditions, and notices associated with this product.

Scan the QR Code for More Operation Steps

Important Safety Information

Please follow these important instructions while training the appliance to ensure your dog's safety and comfort!

WARNING

WARNING denotes a potentially dangerous scenario that, if ignored, might result in the dog's health or serious injury.

1. Scrape/sandblast any children's wishes, and keep away from pets.
2. Do not shock the dog's health or the dog's health.
3. Don't charge this product with a charger of more than 5 volts.
4. Don't shock the dog's health or the dog's health.
5. Do not attach the dog leashes to the training collar.
6. Do not use the device on dogs with pacemakers or other implanted medical devices, and are not recommended for aggressive or timid dogs.
7. Do not use this product in areas where it is prohibited.
8. It is forbidden to use the product extremely dangerous, such as Serious or extremely cold (below 0 degrees Celsius) environments.
9. Do not use this product in areas where it is prohibited.
10. Do not use this product in areas where it is prohibited.
11. Do not use this product in areas where it is prohibited.
12. Do not use this product in areas where it is prohibited.

Operating Environment & Maintenance

Do not use the product in the circumstances as follow :

1. Do not use the product if it becomes ineffective due to a drop, damage, or other cause, and seek professional attention. To avoid harm, the manufacturer or dealer will not be responsible for any damages caused.
2. When the device is not in use, disconnect it from the power source and store it in a cool, dry place away from direct sunlight and moisture. Switch off the device, turn off the receiver, cover the rubber lid tightly on the Receiver's charging port, and store the set in a cool, dry location.
3. Do not use the device in extreme temperatures, as it may affect the battery's lifespan and might scratch the device's surface.
4. If the Receiver has become filthy, reduce the rubber cap on the charging port.
5. This product is intended for professional dog training purposes only and should not be used for any other reason. Please do not use this product in violation of any laws.

Contents

Activate Your Warranty 2
Important Safety Information 3
Important Training Guide 8
FCC Warning 9
Product Overview
Operating Guide
Charging Prior to Use 4
Product Switching ON/OFF 5
Pairing the Remote Control and the Receiver 7
Pairing Additional Receivers 7
Finding the Most Appropriate Level 8
Test the vibration function 9
Test the beep function 9
Test the LED lights function 10
Proper Fit of the Collar 11
Training Modes
Training Level Vibration/Shock Level 13
Training Modes & Key Functions 14
How to Exit Beep/Vibration/Shock/Tone Mode 16
Frequently Asked Questions (FAQs) 18
Operating Environment & Maintenance 20
Warranty Service 21
Terms of Use and Limitation of Liability 22

Frequently Asked Questions (FAQs)

Q - What could I do if the receiver did not respond to the operational signals from the remote control?

A -

1. Verify the Receiver Collar is or had been matched.
2. Check your Remote, make sure the Receiver is in the correct channel.
3. Check the Receiver's battery level, make sure it is charged to have enough power. If the Indicator Light does not come on when any button is pressed on the Transmitter, ensure that the batteries are fully charged.
4. If did not resolve the problem, see page 8 to rematch them.

Q - What can I do if I press the remote control button, but the pooch does not react?

A -

1. Ensure the receiver is turned on.
2. It's possible that a low battery in the remote control and receiver is causing the problem. Ensure that the receiver is turned on when you test it.
3. The remote control distance can be affected by a variety of factors such as topography, weather, vegetation, and the transmission of other electronic devices.
4. Increase the electric shock or vibration's intensity level. Refer to "How to find the best Vibration/Shock Level" for more information.
5. Ensure that the receiver's electric shock-post contacts are close to the dog's skin.

Product Overview

Function description of the mode per adjustment

1.Press once to adjust the beep intensity.
2.Press downward the gear adjustment button shortly,the beep/vibe intensity will decrease by 1 level,then make the button within 10 seconds to increase/decrease the gears.
3.Tips:When press downward the gear adjustment button,you will find the beep/vibe intensity is at the lowest level,but the receiver vibrates,it is not literally work,it is the normal.The gear adjustment needs to be pressed downward first and then be able to rotate the button. It's to avoid the accidental touch near triggered accidentally.



5. Jumping on People.

Jumping can be an annoying behavior that makes other people feel uneasy. Dogs usually leap to get attention, which is not a desirable trait in a pet dog. If you train a Receiver Trainer, you may take control of your dog's leaping ability.

- Let your dog sit before he can have any attention.
- Ignore your dog when he jumps on you. Don't train your dog's recognition level.
- Reward your dog when he stops jumping on someone, press the stimulation button.
- Press the button 1-2 times.
- Immediately release the stimulation button once your dog sits down.
- Praise your dog.
- Repeat the procedure in several locations and use different people each time.

If your dog is persistent in jumping behavior, repeat the "SIT" command several times before increasing the stimulation by one.

6. Digging up Garden Beds.

Now, your dog may squander hours of your labor and money invested on the garden beds. Digging is a natural behavior for dogs. Dogs dig holes to shelter, search for food, or to cool off. However, it is out of tolerance, but more often if you offer a nice, shaded location for your dog to lie down and lots of toys to entertain him, he will be less likely to dig holes in the garden beds. However, some dogs are extremely strong- willed, - and utilizing an electric dog training collar may help resolve this issue. How to use a Dog Trainer to train your dog to stop digging in the garden?

- Choose a stimulation level and begin his/her your dog recognition level.
- Leash your dog to the garden bed so your dog does digging.
- Wait for a few moments because your dog will start digging in a garden bed. When he/she receive a shock, the collarwill light and beep.
- Make sure the charging port is dry before charging the device.



3 hours separate charging with USB charging cable

Notes :

- Make the remote control is charging, the battery icon on the display will blink. When the battery is fully charged, the battery icon will stop flashing and display a full status. If the remote control loses power, please charge it in time to avoid affecting the use of the product.
- While charging, the receiver's green LED status light will illuminate and flash in a breathing pattern. After fully charged, the green LED status light will stop breathing and remain on. While charging, the remote control's screen will display a charging animation. When the battery is fully charged, it will transition to showing a static battery icon.
- To extend the lifespan of the battery, it is recommended to charge the receiver collar if the receiver is not in use for more than 3 months.

Teach Basic Commands

There are a few new instructions that you may teach your dog. "Sit", "come", "stay", and "heel" – these orders may seem simple, but they can definitely come in handy.

1. The Sit Command.

So, how do you teach the "SIT" command to your dog? It's pretty simple - you'll need to use the Remote Trainer and the Receiver Trainer.

- Leash your dog and let him sit next to you.
- Say "sit" and clarify it.
- It should be above the remote training (receiver) collar.
- Press the button.
- The extra collar should not put pressure on the remote training collar's neck. Make sure the collar is not too tight.
- Hold the leash and the Dog Remote Trainer on one hand.
- Press the button on the Dog Trainer to activate the sitting position.
- Press and hold the sitting position.
- Immediately give the "SIT" command.
- Release the stimulation button.
- Praise your dog as soon as your dog is in the sitting position.
- Release the stimulation button.
- Praise your do.
- Reward your dog for his desire from the sitting position.
- Pay for a few moments.
- Repeat the process until your pet understands the command.

2. The Come Command.

Teaching your dog to come is a crucial recall position might be a critical safety factor. Using a remote dog training collar, this is fun! Use the following tools:

- Keep the leash and the Dog Remote Trainer on one hand.
- Hold the leash and the Dog Remote Trainer on one hand.
- Say "come" and clarify it.
- Activate the stimulation button.
- Immediately give the command "COME".
- Immediately grow the command "COME".
- Release the stimulation button as soon as your dog obeys towards you.
- Praise your dog verbally or pet him.



1. Press the receiver's power switch button, the receiver is switched on, the LED indicator will flash once, while the receiver makes a tick sound twice.
2. To switch off the receiver, press the power switch button again, the receiver is switched off, the LED indicator will flash again, while the receiver makes a tick sound twice.
3. If the receiver is switched on but there is no signal, it will make beep every 7 seconds to remind you it is standalone and ready to receive signals from the remote control.

Note :

After a period of inactivity, the receiver enters standby mode, and its backlight is dimmed to prevent the screen from burning in. Short for a few moments because your dog may start digging in a garden bed. When he/she receive a shock, the collarwill light and beep.

Test Training Modes

⚠ WARNING

1. The metal probes is already installed on the collar. There are couples silicone probe covers in the box, the silicone protective cover can be applied to the probes to protect the dog's skin from shock or irritation. Please remember to remove the silicone probe covers before you attach to the dog's hair, if the dog's hair is very long, just choose the dog's neck.



2. Allow your dog to wear the electric training collar for a few days to a week before to beginning active training. This is to acclimate the brief in your dog that the collar is just like any other collar. this will prevent your dog from associating the collar with pain. Your dog should be reprimanded with the undesirable behavior and NOT with the remote training collar.
3. Ensure that When Fitting the Electric Dog Collar! The pain on your dog's skin is frequently caused by over-tightening the electric dog collar. This is a typical error made by the majority of dog owners. If once you're finished fitting the collar, you should be able to slide two fingers in between your dog's neck and collar. You should allow the skin on your dog's neck to breathe and move freely.
4. Attaching a lead to the electronic dog collar will increase the collar's tightness, which we want to PREVENT. As your dog pulls against the lead, the collar will tighten around his neck. Please don't attach a lead on your dog's neck, eventually causing soreness. As a result, contact your dog's neck, and irritation. Instead, put on a lead to the ring of the collar or harness for your dog.



Test Training Modes



1. Test the electric shock function.

- Put the collar on your dog's neck and adjust the intensity level to the lowest level.
- Press the shock button.

2. Test the vibration function.

- Put the collar on your dog's neck and adjust the intensity level to the lowest level.
- Press the vibration button.

3. Test the beep function.

- Put the collar on your dog's neck and adjust the intensity level to the lowest level.
- Press the beep button.

4. Shock Mode Description

Shock mode adjustment: in shock mode, press the top knob down and then the shock symbol will flash on the screen. Rotate the gear adjustment button 10 seconds to adjust the intensity between 0-99 levels.

Special instructions: When the shock is not required, please turn the shock level to the shock position to turn off the shock function.



Scan the QR Code for More Operation Steps

5. Test the LED Light

- **Short press** the light button on the right side of the remote control, the LED light of the receiver will stay on, short press again to turn it off.
- **Long press** the light button for 2 seconds, the LED light of the receiver will enter the flashing mode (the flashing mode lasts for 60 seconds, and it will automatically turn off after 60 seconds).
- In the flashing mode, short press the light button again to turn off the LED.

Activate Your Warranty

www.slope-hill.com

or scan the QR code to know more.

30 Day Money-back Guarantee 60 Day Refund 1 Year Quality Warranty

Customer Service Team:

support@slopehill.com
+1-732-762-2943

FCC Warning

This equipment has been tested and found to comply with the limits for a Class B digital device pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates,uses and can radiateradio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipmentOff and on, the user is encouraged to try to correct the interference by one or more of thefollowing measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 5cm between the radiator and your body.

Important Training Guide

Please follow these important Training Guide while using the product to ensure your dog's safety and comfort!

WARNING denotes a potentially dangerous scenario that, if ignored, might result in the dog's health or serious injury.

1. Do not be a substitute for your dog's health and safety. Please note that dog's will have an adverse reaction to the sound or shock during training. Therefore this is why other trainer will be beneficial to your dog.
2. Please read the instructions carefully before using the dog. Fit to your dog's neck according to the instructions in this booklet.
3. Use a separate collar for a lead, don't put pressure on the electronic collar.
4. Please do not use the product if your dog's skin is irritated or injured. Keep the dog within a safe range at all times and that you can easily draw the dog back if it escapes unexpectedly.
5. Please do not use the product if your dog's skin is irritated or injured. Keep the dog within a safe range at all times and that you can easily draw the dog back if it escapes unexpectedly.
6. Training start with the lowest level of stimulation.
7. Training start with the lowest level of stimulation.
8. Training your dog with food will usually contribute to the achievement of the best result.
9. Utilize verbal commands initially, and only when necessary, supplement with the remote trainer. Timing is crucial when delivering a correction; contact by utilizing the same phrase each time. Try a word, work with your pet on a single habit at a time.
10. Remember that the dog is conditioned to reinforce spoken orders. Avoid excessive corrections with your dog. For instance, by pushing the Beep Button, you may utilize the sounds as a warning. The dog will develop a connection between the sound and the stimulation and will quickly learn to associate the beep with your spoken order.
11. Eliminate or teach one misbehavior or obedience order at a time. Don't overwhelm your dog with too many new commands or corrections.
12. Always keep an eye on the dog's reaction and make sure the receiver has not fallen off.
13. Please turn the receiver and the collar every 1~2h, adjust the position and tightness if necessary to prevent excessive pressure.

Warranty Service

1-Year Limited Quality Warranty

We warrant the items as of the purchase date. Kindly scan the QR code located on page 2 or visit **www.slope-hill.com** to register for your warranty and activate it.

Any unauthorized repairs or modifications will void the warranty. Please note that this is only other trainer will be beneficial to your dog.

Please contact us if you have any issues with your product. Fit to your dog's neck according to the instructions in this booklet.

Not covered by the warranty

1. All product must be accompanied by evidence of purchase in order to begin warranty repair service.
2. Damage caused by accident or misuse or to a product that has been modified by another vendor, we cannot provide a guarantee.
3. Damage caused by failure to perform recommended adjustments caused by using the same phrase each time. Try a word, work with your pet on a single habit at a time.
4. Any water damage to our product voices "Rainproof Receiver" and "Waterproof Receiver" are incorrect. The owner is responsible for any injury caused by improper treatment.
5. The warranty is invalid if the product has been modified or if an unauthorized individual has caused damage to the product during repair attempts.
6. We strongly advise customers not to change the batteries within the warranty period. Any damage caused by the user will void the warranty.
7. Any damage caused by the user will void the warranty.
8. Please contact us if you have any issues or discard any accessories that are damaged during replacement or repair.

Package Content



Q - What should I do if the dog trainer does not work?

A -

1. Check the power level of the remote control receiver and recharge it in time.
2. Use receiver or electrical shock mode, check the intensity level and ensure that it is not at the lowest point.
3. If the receiver is smashed, please press the power switch button to turn it off.
4. Check the Dog Collars, press the Cirbutton to turn it back on if you have picked another channel.
5. Re-pairing the remote control and receiver.

Q - What should the duration of each dog training session be?

A - 10~15 minutes.

Q - Receiver Beeps, Vibrates, sending Static by itself constantly or occasionally.

A. Make sure no button of Remote has been pressed or gotten stuck. Match Receiver to the Remote Control again.

Q - The training mode fails to sync up even in a short distance.

A. Ensure the receiver is not in standalone interference in your surroundings. The Remote's range could fluctuate subject to obstacles, electromagnetic fields, or even stormy weather.

Q - The Receiver Collar will not turn on.

A. Ensure the Receiver's battery is not low or been charged. For the initial charge, be sure to charge it for 2~3 hours. Subsequent charges only take 1.5~2 hours.

Product Overview



7. Chasing Cars and People.

Dogs love to chase cars, people, and even cats, especially if your dog enjoys going on walks. Dogs adore chasing, don't they? Yes, ... it is. Remote Dog Training can assist you in resolving this very dangerous habit. Here's how:

- Leash your dog to a tree. - needs to be trained for recall using the "COME" command.
- Make sure your dog understands and masters the "COME" command.
- Wait for your dog to chase a car or dog higher than your dog's recognition level.
- Press and hold the stimulation button.
- Immediately grow the "COME" command.
- Release the stimulation button as soon as your dog obeys towards you.
- Praise your dog verbally or pet him.

8. The Heel Command.

As a rule, good leash behavior is critical, as is keeping your dog near to you off- leash. Utilize an Electric Dog Training Collar to teach your dog to heel. Here's how:

- Shorten the leash so your dog can walk right beside you.
- Slowly release the leash.
- Activate the stimulation button, press the stimulation button.
- Immediately grow the command "HEEL".
- Use the leash to gently pull your dog back to make him understand what is the command.
- When your dog returns to your side, release the stimulation button.
- Praise your dog or give him food treats.
- If your dog is persistent in chasing behaviors, it will be easier for you to reinforce positive behaviors.

Now, unpleasant behaviors such as jumping on people, digging in your garden, and chasing automobiles and other undesirable behaviors barking can also be corrected by using remote dog trainers.

Product Switching ON/OFF

1. To switch on the remote control, press and hold the ON/OFF button on the remote control's side for about 3 seconds.
2. To switch off the remote control, press and hold the ON/OFF button in the OFF position.



Notes :

1. After the remote control is switched on, the display backlight will remain on for 5 seconds; if no further activity is done, the backlight will turn off to save power. The backlight will turn on when any button is pressed. If there is no activity for 5 minutes, the LCD display will switch off after 1 hour and can be switched back on by hitting any button on the Remote control.

3. The Stay Command.

Oftentimes, when people arrive at your house, you want your dog to remain in the area, instead of a side to side of the entry. Here's how to teach your dog to stay:

- Put your dog on his designated spot.
- Walk within the proximity of the spot but stay within 3 feet.
- Don't say anything unless your dog tries to leave.
- If your dog tries to leave, press the stimulation button.
- Immediately grow the "STAY" command.
- Hold the button until your dog is back at its spot.
- Release the button as soon as your dog obeys the move.
- Praise your dog verbally or pet him.

Pairing the Remote Control and the Receiver

You may skip this step if the product is already matched up in the factory. (The paired channel is CH1.)



1. Turn on the remote control and press the CH button to choose "CH1".
2. Turn on a Receiver and press the power button of the Receiver by 2 seconds, the LED indicator will flash once, while the receiver makes a tick sound twice.
3. Press and hold the Beep button and Light button on the top of the Remote control within 10 seconds after the beep sound, hearing a beep sound again that means the pairing successful.

Pairing Additional Receivers



You can select a different pairing channel to couple an extra receiver or two in the same manner as described above.

Finding the Most Appropriate Level of Electric Shock For your Dog

Training your dog is very challenging. First select an area (or the environment) that is free from distractions.

Ascertain that both the portable remote (transmitter) and the collar (receiver) are fully charged and operational.

1. Follow these steps to smoothly start training your puppy with the tone button :

- Spend 10~15 minutes per day for 2~3 days helping your dog understand the tone.
- Associate the tone with a favorite treat and praise (some use the tone as a warning).
- Repeat the procedure for 2 seconds.
- Reward your dog with some treats.
- Allow 2~3 seconds before you repeat the process.
- Repeat 10~15 times per session for the tone function.
- As soon as your dog starts to anticipate a reward with the tone, you're succeeded in the phase.

2. How to find the best Vibration/Shock Level – the level that your dog responds to, but doesn't react to, these steps :

- Start with the lowest(1) level of stimulation.
- Look for a slight change in your dog's behavior.
- Lightly scratch your dog.
- Something at his remote training collar.
- Praise your dog.
- If you do not see any changes at his behaviour, move up to the next level of stimulation.
- Repeat the process your dog's reaction to the stimulation.
- Take note of his recognition level – the level you use for communicating with your dog.

Proper Fit of the Collar

1. Turn off the collar before to attaching it to your dog – this is to avoid accidental shocks. Attach the collar to your dog's neck and position it with you (not with the behavior you are attempting to address).
2. Allow your dog to stand comfortably. DO NOT fit the collar while your dog is sitting down – your dog's neck is a bit smaller in sanding position.
3. If your dog has thick fur, please use a comb to separate the fur around the contact points before you put on the collar.
4. Place the Receiver around the neck of the dog. The collar should be tight, but the contact areas should feel comparable to how you would feel wearing a necklace – snug but not uncomfortable.
5. Put your dog's collar on so that it is over your thyroid between the collar strap and the dog's neck. If one finger can be placed between, the fit is optimal.
6. The silicone caps may help to dull the static sensation. You should remove the silicone caps when you are using the collar on your dog's hair. Please remember to remove the silicone caps with the electrodes, since in some cases might cause pain in some dogs.
7. Allow your dog to become accustomed to the collar by allowing him to wear it for a few minutes.
8. Turn on the collar to level 15.
9. Turn on the collar to test it or begin training.