NXGKET Walkie Talkies
Getting Started

Button	Times to Press	Function	Level	Steps
MENU	Press & Hold 3-4s	keyword locked		Press & Hold ”Menu” button for 3-4s, the keyword will be locked and unlocked
	1	Channels	22 Channels	Use **+/-** to choose the channel, press PTT to save.
	2	Sub-Codes	121 Sub-Codes	Use **+/-** to choose the Sub-Codes, press PTT to save.
	3	Call Tone	10 Call Tones	Use **+/-** to choose the Call Tones, press PTT to save.
	4	VOX Sensitivity	1,2,3	Use **+/-** to choose the VOX sensitivity, press PTT to save.
	5	Double Channel	22 Channels	Use **+/-** to choose the channel, press PTT to save.(Choose to close Double Channel)
	6	Squelch Level	6 Level	Use **+/-** to choose the squelch sensitivity Level,press PTT to save.
	7	Power	HI/LO	Use **+/-** to choose HI/LO power. Press PTT to save.
Function Setting		MON Button		Press ”**MON**” button for 1 time, walkie talkie will transmit call tone to another walkie talkie.
		Power Button		1.Press & Hold ”**Power**” button for 3-4 Seconds, walkie talkies will turn ON/OFF. 2.Press ”**Power** ” button for 1 time, walkie talkie will auto scan channel from 1 to 22, you can press”PPT”button in another walkies talkie, it will detect and match the same channel of walkie talkie.
		Turn on VOX		Please trun off the walkie talkies ,Press & Hold ”**Power** and **PTT**” button for 3-4 Seconds, walkie talkies will Turn on VOX function, Press “PTT” button to cancel the VOX function.
		Volume	16 Level	Use **+/-** to adjust the volume of walkie talkie.
		Default Setting		Please trun off the walkie talkies ,Press & Hold ”**MENU** and **Power**” button, walkie talkies will reset factory default setting.

Warm Note:

1.If walkie talkie transmission distance is short, Please make sure power setting is “**HI**” in the menu.



2.If walkie talkies keep switching back and forth between channels, you can enter setting menu and turn off double channels function, or reset walkie talkies for factory default setting.

3.If walkie talkie can not keep in touch with each other, Please check channel and eliminator code setting is the same.



4. if walkie talkie cann’t turn on, Please check if the walkie-talkie is out of power and needs to be charged.