MERACH S08 Recumbent Bike Troubleshooting Guide

This guide provides useful tips and solutions for troubleshooting our brand of fitness equipment, as well as scenarios of possible accessory and Bluetooth (App) problems.

Pedals can not be installed

Make sure the "R" and "L" marks on the crank are aligned with the "R" and "L" marks on the pedal respectively before installing the pedals.

Loose pedals while riding

Check whether the locking nuts of the pedals are tight enough.

Monitor no data display

Check whether the batteries are installed correctly.
Replace the batteries.

There is a noise when pedaling

Check if all the connection nuts are tight enough.

How do I troubleshoot Bluetooth connection issues?

Please follow these steps:
1. Check if the machine is powered on.
2. Make sure the Bluetooth indicator light is on by waking up the machine.
3. Ensure that the Bluetooth function on your phone is turned on.
4. Make sure no one is using the machine during the Bluetooth connection.

What should I do if I find missing parts when installing the machine?

Our package is very compact, please check if all the parts inside the package have been taken out first.
If you cannot find the corresponding parts, please feel free to contact us.

WARM TIPS

- No matter you encounter any problem in the installation or use, you can always contact us through support@merach.com

IMPORTANT!

Please read all details before use, and keep this guide for future reference.

PLEASE CONTACT US BEFORE THE RETURN:
Mon-Fri,9:00 am-5:00 pm PST/PDT

support@merach.com