Descaling Steps for the Warriors1 SV835L Coffee Machine

(EN)

IMPORTANT REMINDER

When the green lights of all three buttons flash slowly simultaneously, please be aware that this is not a fault. It is a reminder that the machine requires descaling



NOTE

1. Please refer to Chapter 7, "Descaling and Daily Cleaning", in the manual to perform the descaling operation
2. The descaling reminder will not affect your ability to continue brewing coffee, but the system will continue to remind you to descale after each brew
3. Use a dedicated coffee machine cleaner or diluted citric acid for descaling. Do not use white vinegar or any other strongly corrosive cleaners
4. If you manually turn off the machine during the descaling process, that cycle will not count toward the three descaling cycles.
5. If you still notice any residual taste after the process, a further rinse with fresh water may be required

• SV835L Coffee Machine Regular Descaling - Descaling Reminder

Reminder Phenomenon:

Three green lights blink simultaneously, alternating between on and off, with a 1-second interval.

Reminder Condition:

200 extractions.

How to Clear the Reminder:

Activate the descaling program.

Materials and Tools Required for Descaling:

1. Water: Fill the water tank with 800ml of water.
2. Descaling Agent: Citric acid or a coffee machine descaling agent. If using citric acid, the recommended ratio is 1:10, so use 80ml (or mg) of citric acid. If using a coffee machine specific descaling agent, please dilute it according to the instructions on the descaling agent package.
3. Cup: An empty cup with a capacity of more than 300ml.
4. Adapter: It is recommended to use an empty Nespresso adapter for cleaning. If you do not have a Nespresso adapter, you can use an empty Dolce Gusto adapter.
5. Waste Container: During the descaling process, at least one 800ml container is needed to dispose of the waste water collected from the cup.

Preparation:

- Add 80ml of citric acid and 800ml of water into the water tank, mix well.
- Insert the empty Nespresso adapter into the extraction head (note: do not place a capsule inside).
- Place an empty 300ml cup on the cup holder.

Activating the Descaling Program:

1. Press any button to turn on the coffee machine; the green light will illuminate.
2. Briefly press the **medium cup** and **large cup** buttons simultaneously, then release them. Wait for the **small cup** button to light up and the **medium** and **large cup** buttons to turn off. This indicates that the descaling program has been activated.

Note: Once the descaling program is activated, the machine will automatically proceed with water extraction using the small, medium, and large cup buttons.

Descaling Program in Progress:

1. The machine will automatically start with the **small cup** button, and the **medium** and **large cup** buttons will turn off: Extract 200ml of waste water. The program will automatically pause for 10 seconds. Please manually dispose of the waste water from the cup.
2. The machine will automatically start with the **medium cup** button, and the **small** and **large cup** buttons will turn off: Extract 200ml of waste water. The program will automatically pause for 10 seconds. Please manually dispose of the waste water from the cup.3. The machine will automatically start with the **large cup** button, and the **small** and **medium cup** buttons will turn off:
Extract 200ml of waste water. The program will stop automatically. Please manually dispose of the waste water from the cup.
4. The lights on the **small**, **medium**, and **large cup** buttons will remain on, and the descaling reminder light will be extinguished, indicating that the descaling program has been successfully completed.

Note: If any button is pressed during the descaling program, the process will be interrupted. In this case, the descaling process will not be completed, the counter will not reset, and the descaling reminder light will not be extinguished.

• SV835L Coffee Machine Manual Descaling

Applicable to products with SN M0201B2504D (inclusive) or later

In addition to the automatic descaling program, Warriors1 features a manual descaling mode designed to clear potential blockages caused by poor water quality.

Preparation

Refer to the materials, tools, and preparation steps described in “Regular Descaling”.

Start Manual Descaling

Press and hold the Large Cup button without releasing it, then plug in the power cord. After 5 seconds, the machine will automatically enter manual descaling mode.

Descaling Process

The manual descaling process follows the same sequence as the regular descaling program.

Note: Once manual descaling is completed, the brewing cycle counter will reset to zero. The machine will prompt for descaling again after 200 brewing cycles.

After the Descaling Program Ends, Start Cleaning the Machine to Ensure It is Safe for Drinking:

Please refer to **Chapter 5** of the manual, "Cleaning the Machine Before First Use.