24.11.18日更新了二维码

展开26x18cm的， 128g铜版纸单面彩印对折，单面印

Quick Setup Guide

IMPORTANT: The default Master Code is **123456**.
It is required that you change it to your own before programming.
The password can be set to 4~9 digits.

Change Master Code	Press SET Flashing green light	Master Code +	Press 4 +	New Master Code +	Re-enter New Master Code + Success Flashing green light	
Add User Code	Press SET Flashing green light	Master Code + Flashing green light	Press 1 + Flashing green light	User ID (2-digit) + Flashing green light	New User Code + Flashing green light	Re-enter User Code + Success Flashing green light
Delete User Code	Press SET Flashing green light	Master Code + Flashing green light	Press 2 + Flashing green light	User ID (2-digit) + Flashing green light	Re-enter User ID + Success Flashing green light	
Delete All User Codes	Press SET Flashing green light	Master Code + Flashing green light	Press 3 + Flashing green light	Master Code + Success Flashing green light		
Set Auto Lock	Press SET Flashing green light	Master Code + Flashing green light	Press 5 + Flashing green light	Time (5-30 s) + Success Flashing green light		
Cancel Auto Lock	Press SET Flashing green light	Master Code + Flashing green light	Press 5 + Flashing green light	0 0 + Success Flashing green light		
Sound On or Off	Press SET Flashing green light	Master Code + Flashing green light	Press 6 + Flashing green light	1 or 2 + (1=Sound Off) (2=Sound On)		

Get 24/7 Assistance at

Use camera or QR scanner to scan

Visit: https://elamor2.afterservice.vip
Call: +1 (833) 553 0238 (US Toll-free)
Email: elamor2@afterservice.vip

Notes:

1. If the indicator light flashes red, it means your setting failed. To continue your programming, press **SET** to re-enter programming mode.
2. The **SET** button is inside the battery compartment.
3. When you enter a wrong button, you can press to clear it.

B