FPCN10A Trouble Shooting

No Power	The battery may have been exhausted.Please recharge or replace the battery pack.The battery pack may not be installed correctly. Please check and install it again.
Unable to talk or hear members in your group	Make sure you are using the same frequency and CTCSS tone as other members in your group. Other group members maybe too far away from you , make sure you are in the radio's operation range.
Poor audio quality, static, noise and interference	1.Re-turn on the radio 2.Adjust Volume 3.Do not put two stations too close,keep a distance of 12 feet would be better.
The voice is not clear and loud	Adjust the volume first and check whether the MIC is blocked
Can't talk to other Intercoms (Like FTAN10A/FTAN20A/FTAN30A Model	Please check all station's switch are set to A position and same channel