Safety Instructions

*Please read the following instructions carefully before using the J400 Jump Starter:
1. Please operate in strict accordance with the instructions. Improper operation may lead to serious safety accidents;
2. The starting power supply is only used for 12V starting, and cannot start vehicles exceeding the specified displacement or exceeding the specified voltage (12V);
3. Manual start mode: In this mode, some safety protection mechanisms are disabled and need to be used with caution. Be sure to prevent the positive and negative poles from being short-circuited, otherwise it will cause a short-circuit accident. You must check the operating instructions in the manual before operation;
4. In order to extend the service life of J400, please charge it after receiving it, and charge and discharge the device every three months to ensure that the J400 is in good condition for next use;
5. Do not use the J400 that has been excessive shocked, dropped or other forms of damage.
6. Do not use the J400 to start the vehicle while the product is in charging;
7. Please do not disassemble the starting power supply without authorization. Please contact professional maintenance personnel to repair and deal with the abnormal starting power supply;

8. Be extremely careful during operation to avoid metal tools falling on the startup power interface (which can easily cause short circuit, equipment damage, and explosion);
9. When jump starting the car, make sure that the positive and negative poles of the starting power cable clamp are in good contact with the positive and negative poles of the battery;
10. It is forbidden to allow sparks and flames to come close to the starting power supply and engine;
11. In order to prevent sparks from short circuit and damaging the starting power supply, it is forbidden to clamp the positive and negative terminals together or touch the same metal;
12. Please do not place the starting power supply in a place easily accessible to children;
13. Do not expose the starting power supply to rain or snow;
14. Do not leave the device in extreme environments for a long time (such as high temperature: >131℉ (55℃), extreme cold: <14℉ (-10℃), humidity: humidity >80%);
15. Please store the starting power supply in a cool and dry place, and take protective measures when necessary;
16. When the J400 is exhausted or has low battery, please charge it in time to prevent abnormal battery undervoltage. Long-term zero battery status may cause the J400 to be unable to charge.