get started

INSTANT® **VORTEX™ PLUS** 6QT WITH **CLEARCOOK**

Instant®

140-3088-01-0303_IB_VortexPlus_6QTseethruSS_US_GSG_FINAL.indd 1 12/6/21 2:55 PM

Welcome

to your new Instant Vortex Plus!

This Instant Vortex Plus Air Fryer can help you cook delicious meals with less oil and less hassle. We hope you fall in love with Instant air frying and enjoy it in your kitchen for years to come!

Learn more about your Vortex Plus

⚠WARNING


Before using your new Vortex Plus, read all instructions, including the Safety and Warranty document. Failure to follow the safeguards and instructions may result in injury and/or property damage.


CONTENTS

What's in the box	2
Using your Vortex	4
Initial set up	6
Cooking	8
Smart Programs	10
Cleaning	13
Learn more	14


WHAT'S IN THE BOX

Air Fryer





Cooking tray



Air Fryer basket with ClearCook window

Illustrations are for reference only and may differ from the actual product.

Remember to recycle!


We designed this packaging with sustainability in mind. Please recycle everything that can be recycled where you live. Be sure to keep this Guide, along with the Safety and Warranty insert for reference.

140-3088-01-0303_IB_VortexPlus_6QTseethruSS_US_GSG_FINAL.indd 2 12/6/21 2:55 PM

USING YOUR VORTEX

Control panel

We've designed the control panel to be simple to use and easy to read.



1. Time/Temperature
   - Cooking time
   - Cooking temperature
   - Messages
2. Smart Programs
   - Air Fry
   - Roast
   - Bake
   - Reheat
   - Broil
   - Dehydrate
3. Control Dial
   - Used to select time and temperature
4. Temperature and time
5. Cancel
6. Light
   - Turn on or off the internal cooking light
7. Start

140-3088-01-0303_IB_VortexPlus_6QTseethruSS_US_GSG_FINAL.indd 3 12/6/21 2:55 PM

Turning cooking light On/Off

- To turn the light on, press **Light**.
- To turn the light off, press **Light** again. The cooking light cannot be turned off in the last 60 seconds of a cooking program.

Turning sound On/Off

- While in Standby mode, press and hold **Temp/Time** and **Light** for 5 seconds, until the display shows **Sound Off** or **Sound On**.

Audible safety alerts (beeps) cannot be turned off.

Choosing temperature unit

Choose which cooking temperature unit you would like to use, Fahrenheit or Celsius.

- While in Standby mode, press and hold **Temp/Time** for 5 seconds, until display shows °F or °C.

Save custom settings

You can set and save custom time and temperature settings for any of the six *Smart Programs*.

1. Select the Smart Program you want to set.
2. Press **Temp/Time** button and use the Control Dial to change the temperature and time.
3. Press **Start Button** to confirm change.

The next time you use that Smart Programs the new temperature or time is used. Adjustments made after cooking begins are not saved.

140-3088-01-0303_IB_VortexPlus_6QTseethruSS_US_GSG_FINAL.indd 4 12/6/21 2:55 PM

Reset Smart Programs to original settings

Reset individual Smart Programs

- With the cooker in Standby mode, press and hold one of the Smart Program buttons until the cooker returns to Standby.

Reset all Smart Programs

- With the cooker in Standby mode, press and hold the **Control Dial** until the cooker beeps.

All Smart Program cooking times and temperatures are restored to the factory default setting.

Cancel active cooking program

You can cancel any cooking program at any time.

- While in Standby, Preheating or active cooking program, press **Cancel**. Depending on the temperature of the unit, the internal fan may keep running to cool the unit.

140-3088-01-0303_IB_VortexPlus_6QTseethruSS_US_GSG_FINAL.indd 5 12/6/21 2:55 PM

INITIAL SET UP

Unpack

1. Remove your new Vortex Plus from the box.
2. Remove all the packaging material from in and around the air fryer.
3. Make sure to remove all the accessories from inside the cooking chamber.
4. Don't remove the safety warning stickers or the rating label from the air fryer.

Clean before use

1. Wipe the interior with a damp cloth. Use a clean, soft cloth to dry.
2. Wash the accessories with hot water and dish soap. Rinse with warm, clear water and use a soft cloth to dry.

Placement

1. Place your Vortex Plus on a stable, level surface, away from combustible material and external heat sources. Do not place your Vortex Plus on top of another appliance.
2. Make sure to leave at least 5 in / 13 cm of space above and around all sides of the appliance to allow for sufficient air flow.

Test run

Before using your new Instant Vortex Plus for the first time, you must perform a test run to ensure everything is working correctly.

140-3088-01-0303_IB_VortexPlus_6QTseethruSS_US_GSG_FINAL.indd 6 12/6/21 2:55 PM

To perform a test run:

1. Follow the instructions for cooking on page 10.
2. Insert the cooking basket, but do not add food.
3. Select the Air Fry program.
4. Select the cooking temperature (400°F / 205°C).
5. Select the cooking time (18 minutes).
6. When the display shows **Add Food**, just remove and reinsert the cooking basket (do not add any food).
7. When the display shows **Turn Food**, wait 10 seconds for the program to resume.
8. After the cooking program ends, allow the unit to cool down.

Now you're ready to cook a meal in your Instant Vortex Plus!

140-3088-01-0303_IB_VortexPlus_6QTseethruSS_US_GSG_FINAL.indd 7 12/6/21 2:55 PM

COOKING

The Vortex Plus uses rapid air circulation to crisp or cook food, giving your meals all the rich, crispy flavor of deep frying, with little to no oil.

⚠WARNING

HOT SURFACES
The air fryer will be hot during and after cooking. Always exercise extreme caution when removing food from the hot cooking chamber. Touching hot surfaces may result in personal injury, and/or property damage.

MUST ALLOW AIR FLOW
To prevent personal injury, do not block air intake or air vents.

What to cook in

The cooking basket with cooking tray is perforated to allow air to flow under and around your food, and should be used for most foods, like wings and cauliflower bites.

For the Baking program only, you can use a metal or glass baking dish to hold things like batter for cakes and dough for breads. Place the baking dish inside the cooking basket for baking.

You can place food right on the cooking tray, without using foil or other coverings.

Prep

Cut, chop, season, marinate or batter your ingredients according to your recipe.

Cook

1. Place your food into the air frying basket, according to your recipe.
2. Insert the air frying basket into the cooker.

   When the air frying basket is inserted securely, the front of the basket is flush with the front of the cooker.

140-3088-01-0303_IB_VortexPlus_6QTseethruSS_US_GSG_FINAL.indd 8 12/6/21 2:55 PM

3. Press **Air Fry**.
4. Press **Temp/Time** to adjust the temperature and cooking time.
5. Press **Start** to begin. The display shows **Preheating** to indicate that the cooking program has started.

See page 12 to adjust Smart Program settings.

Add food

1. When the cooker passes the preheating phase, the display shows **Add Food**.
2. Remove the basket, and carefully insert your food into the basket.
3. Reinsert the air frying basket into the cooker and the cooking countdown timer starts.

Turn

1. Part way through the cooking cycle the display shows **Turn Food**.
2. Remove the air fryer basket from the unit and carefully turn, flip, or rotate your food.

   *If you do not remove the basket after **Turn Food** displays, cooking will proceed after 10 seconds.*

3. Insert the air frying basket into the cooker. Cooking continues.

Finish

- When the Smart Program completes, the appliance beeps, and the display shows **End**.

  *The "Food-Ready" beep will come up 1 minute later after **End** (10 beeps in 10 minutes total) if the basket/door is not open.*

140-3088-01-0303_IB_VortexPlus_6QTseethruSS_US_GSG_FINAL.indd 9 12/6/21 2:55 PM

SMART PROGRAMS

Air Fry

You can air fry foods like fries, cauliflower bites, wings, nuggets and more.

Setting	Default	Minimum	Maximum
Temperature	385°F / 196°C	180°F / 82°C	400°F / 205°C
Cooking Time	15 minutes (00:15)	1 minute (00:01)	1 hour (01:00)

To air fry

- Follow the basic instructions for Air Frying.
- Select "Air Fry" as the Smart Program.

Roast

You can roast foods like beef, lamb, pork, poultry, vegetables and scalloped potatoes, for a deliciously tender inside and browned outside.

Setting	Default	Minimum	Maximum
Temperature	380°F / 193°C	180°F / 82°C	400°F / 205°C
Cooking Time	18 minutes (00:18)	1 minute (00:01)	1 hour (01:00)

To roast

- Follow the basic instructions for Cooking.
- Select "Roast" as the Smart Program.

Bake

You can bake foods like breads, cakes, pastries and buns, with the Vortex as your own "mini oven".

Setting	Default	Minimum	Maximum
Temperature	365°F / 185°C	180°F / 82°C	400°F / 205°C
Cooking Time	30 minutes (00:30)	1 minute (00:01)	1 hour (01:00)

140-3088-01-0303_IB_VortexPlus_6QTseethruSS_US_GSG_FINAL.indd 10 12/6/21 2:55 PM

To bake

- Follow the basic instructions for Cooking.
- Select "Bake" as the Smart Program.
- There is no need to turn the food partway through cooking.

  Leave approximately 1 in / 2.5 cm of space around all sides of the baking dish to allow heat to circulate evenly.

Broil

Broiling cooks using direct top-down heating, perfect for melting cheese on French onion soup, and nachos.

Setting	Default	Minimum	Maximum
Temperature	400°F / 205°C	350°F / 177°C	400°F / 205°C
Cooking Time	6 minutes (00:06)	1 minute (00:01)	40 minutes (00:40)

To broil

- Follow the basic instructions in Cooking.
- Select "Broil" as the Smart Program.
- There is no need to turn the food partway through cooking.

Dehydrate

Dehydrating uses low heat over a long period of time to safely dry out food items, like dried fruit, jerky and dried veggies.

Setting	Default	Minimum	Maximum
Temperature	130°F / 54°C	95°F / 35°C	175°F / 79°C
Cooking Time	8 hours (08:00)	1 hour (01:00)	72 hours (72:00)

To dehydrate

- Follow the basic instructions in Cooking.
- Select "Dehydrate" as the Smart Program.
- There is no need to turn the food partway through cooking.

140-3088-01-0303_IB_VortexPlus_6QTseethruSS_US_GSG_FINAL.indd 11 12/6/21 2:55 PM

Reheat

Bring the crisp and crunch back to leftover fries, pizza and stale bread, in just a few minutes.

Setting	Default	Minimum	Maximum
Temperature	280°F / 138°C	120°F / 49°C	360°F / 182°C
Cooking Time	10 minutes (00:10)	1 minute (00:01)	1 hour (01:00)

To reheat

- Follow the basic instructions for Cooking.
- Select "Reheat" as the Smart Program.

  Once this Smart Cooking function starts, the display will show the target temperature and cooking time immediately, there's no preheating time.

140-3088-01-0303_IB_VortexPlus_6QTseethruSS_US_GSG_FINAL.indd 12 12/6/21 2:55 PM

CLEANING

Clean your Instant Vortex Plus after each use. Always unplug the unit and let all parts cool to room temperature before cleaning. Before use or storing, make sure all surfaces are dry.

⚠WARNING

To prevent electric shock, unplug before cleaning.

DO NOT immerse power cord, plug or the appliance in water or other liquid, which may result in electric shock.

Part	Cleaning instructions
Cooking tray	• Dishwasher safe.* • The cooking trays have a non-stick coating. Avoid using metal utensils when cleaning.
Removable air fryer basket	• Dishwasher safe.* • The basket has a non-stick coating. Avoid using metal utensils when cleaning.
Cooking chamber	• Clean with a damp cloth and mild dish soap. • Always check the heating coil and cooking chamber walls for oil spatter and food debris, and clean as needed. • Ensure the heating coil is dry before turning on the air fryer. • To remove baked-on grease and food residue from the cooking chamber, spray with a mixture of baking soda and vinegar and wipe clean with damp cloth. For stubborn stains, allow the mixture to sit on the affected area for several minutes before scrubbing clean.
Power cord	• Clean with a soft, damp cloth or sponge. Wipe dry.

**Some discoloration may occur after machine washing, but this will not affect the cooker's safety or performance.*

140-3088-01-0303_IB_VortexPlus_6QTseethruSS_US_GSG_FINAL.indd 13 12/6/21 2:55 PM

LEARN MORE

There's a whole world of Instant Vortex Plus information and help just waiting for you. Here are some of the most helpful resources.

Register your product
Instanthome.com/register

Contact Consumer Care
Instanthome.com
support@instanthome.com
1-800-828-7280

Instant Recipe App with 1000+ recipes
Instanthome.com
iOS and Android app stores

Cooking charts and more recipes
instanthome.com

How-to videos, tips and more
Instanthome.com

Replacement parts and accessories
Instanthome.com

Join the community

140-3088-01-0303_IB_VortexPlus_6QTseethruSS_US_GSG_FINAL.indd 14 12/6/21 2:55 PM

PRODUCT SPECIFICATIONS

Model	Volume	Wattage	Power	Weight	Dimensions
AFB6132BK	6 Quart 5.7 Litres	1700 watts	120V/60Hz	11.35 lbs. 5.15 kg	in: 14.92 D x 11.81 W x 12.99 H cm: 37.9 D x 30 W x 33 H

140-3088-01-0303_IB_VortexPlus_6QTseethruSS_US_GSG_FINAL.indd 15 12/6/21 2:55 PM

NOTES

140-3088-01-0303_IB_VortexPlus_6QTseethruSS_US_GSG_FINAL.indd 16 12/6/21 2:55 PM

NOTES

140-3088-01-0303_IB_VortexPlus_6QTseethruSS_US_GSG_FINAL.indd 17 12/6/21 2:55 PM

Distributed by Instant Brands LLC
3025 Highland Parkway, Suite 700
Downers Grove, IL 60515 U.S.

instanthome.com

© 2022 Instant Brands LLC
140-3088-01-0303

INSTANT and INSTANT POT
are registered trademarks of
Instant Brands Holdings Inc