IU-20 IU-30

Programming

»If you make a mistake during programming,press the check button repeatedly until the keypad lights up. Then start

PASSCODE

ADDING USER PASSCODE

Press	Press	Press	Enter	Press	Enter	Press	Enter same	Press
✓	1	✓	master passcode	✓	New user passcode	✓	New user passcode	✓

Note : The New User Passcode must be different from all of the Passcodes currently in the lock.

CHANGING THE USER PASSCODE

Press	Press	Press	Enter	Press	Enter	Press	Enter	Press	Enter same	Press
✓	2	✓	master passcode	✓	Unwanted user passode	✓	New user passcode	✓	New user passcode	✓

Note : The New User Passcode must be different from all of the Passcodes currently in the lock.

CHANGING THE MASTER PASSCODE

Press	Press	Press	Enter	Press	Enter	Press	Enter	Press	Enter same	Press
✓	2	✓	master passcode	✓	master passcode	✓	New master passcode	✓	New master passcode	✓

⚠ Note : The programming of the lock is controlled by the master code.
The master code MUST EXIST in the lock and cannot be deleted, but can ONLY be changed.

DELETING USER PASSCODE

Press	Press	Press	Enter	Press	Enter	Press
✓	3	✓	master passcode	✓	unwanted user passcode	✓

DELETING ALL USER PASSCODE

Press	Press	Press	Enter	Press
✓	4	✓	master passcode	✓

PASSCODE

PASSAGE

ENABLE EASY PASSAGE MODE

Press	Press	Press	Enter	Press
✓	5	✓	master passcode	✓

With this EASY PASSAGE MODE active, you can open the door without requiring a passcode.
PRESS ANY KEY to turn off this function when it is no longer needed.

ENABLE ADVANCED PASSAGE MODE

Press	Press	Press	Enter	Press	Press	Press
✓	0	✓	master passcode	✓	1	✓

With ADVANCED PASSAGE MODE active, you can open the door without requiring a passcode. Only UNLOCK WITH MASTER CODE can turn off this function when it is no longer needed.

PASSAGE

BEEPER

ENABLE BEEPER

Press	Press	Press	Enter	Press	Press	Press
✓	6	✓	master passcode	✓	1	✓

DISABLE BEEPER

Press	Press	Press	Enter	Press	Press	Press
✓	6	✓	master passcode	✓	0	✓

The beeper can be turned off if desired. Beeps will still sound to indicate a low battery.

BEEPER

AUTO-LOCK

SET AUTO-LOCK TIMER

Press	Press	Press	Enter	Press	Press	Press	Enter	Press
✓	9	✓	master passcode	✓	3	✓	auto-lock timer	✓

The automatic lock time unit is seconds.
Minimum is 2 seconds, and the maximum is 43200 seconds (12 hours).
Default is 4 seconds.

AUTO-LOCK