COUNTERTOP INSTALLATION


Remove all packing material and accessories. Examine the oven for any damage such as dents or broken door. Do not install if oven is damaged.

Cabinet: Remove any protective film found on the microwave oven cabinet surface. Do not remove the light brown waveguide cover that is attached to the oven cavity to protect the magnetron.

INSTALLATION

1. Select a level surface that provide enough open space for the intake and/or outlet vents.


   a. The minimum installation height is 3.0 ft.
   b. Leave a minimum clearance of 3.0 inches on each side, 3.0 inches on top and 1.0 inch in the rear.
   c. Do not remove the legs from the bottom of the oven.
   d. Blocking the intake and/or outlet openings can damage the oven.
   e. Operation of microwave oven may cause interference to your radio or TV reception.
   Please place the oven as far away from radios and TV as possible.



2. Plug microwave oven into a standard household outlet. Be sure the voltage and the frequency is the same as the voltage and the frequency on the rating label.

NOTE

- Do not install oven over a range cooktop or other heat-producing appliance.
  If installed near or over a heat source, the oven could be damaged and the warranty would be avoid.





The accessible surface may be hot during operation