4 - Slice
Touchscreen Toaster

Instructions Manual For household use only
Save these instructions



Model: KST076AU
Power:120V~ 60Hz 1500W

To get the best out of your new appliance and basic safety precautions, please read this user guide carefully before using it for the first time. We also recommend that you keep the instructions for future reference, so that you can remind yourself of the functions of your appliance.

TABLE OF CONTENTS

Important Safeguards 02

Additional Safeguards 03

Product Introduction 05

Toast Time 06

Operation Instruction 07

User-Maintenance Instrutions 09

Cleaning Instructions 09

To Storage 09

Disposal Information 09

IMPORTANT SAFEGUARDS

When using electrical appliance, basic safety precautions should always be followed including the following:

1. Read all instructions.
2. Do not touch hot surfaces. Use handles or knobs.
3. To protect against electrical shock do not immerse cord, plugs, or (state specific part or parts in question) in water or other liquid.
4. Close supervision is necessary when any appliance is used by or near children.
5. Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
6. Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair, or adjustment.
7. The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
8. Do not use outdoors.
9. Do not let cord hang over edge of table or counter, or touch hot surfaces.
10. Do not place on or near a hot gas or electric burner, or in a heated oven.
11. Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
12. Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
13. Do not use appliance for other than intended use. This toaster is intended for normal household use only.
14. The toaster is exclusive for the use which has been expressed by the manufacturer, Improper use of this product, using it for professional or semi-professional purposes, or not following the instructions in this user manual is to be considered inappropriate and therefore dangerous, it will void the warranty, and we are not responsible for any damages in such cases.
15. Do not open the toaster by yourself. No user serviceable parts inside. Repair should be done by authorized service personnel only.
16. Do not mount unit over or near any portion of a heating or cooking appliance.
17. Do not place airtight containers, plastic or rubber containers, paper, cardboard, or any other flammable materials on top of or inside the toaster during use.
18. Do not immerse the outer casing in water or rinse it under the tap, as there are electronic components and heating elements inside the casing.
19. Do not allow water or other liquids to enter the toaster to prevent electric shock.
20. Do not plug/unplug the toaster into/from the electrical outlet with your hands wet.
21. Do not unplug the toaster from the outlet by pulling on the cord. Always unplug power cord by pulling on plug.
22. Use the toaster on a surface that is horizontal, even, dry, clean, and stable surface. Do not leave the toaster exposed to the elements (rain, direct sunlight, frost, etc.).
23. The unit will emit some heat. Allow sufficient space around the unit when in use, it is better leave at least 10 cm of free space behind, on the sides, and above the toaster, do not place the toaster against a wall or other products, especially or near flammable materials such as tablecloths or curtains.
24. The metal sides of the toaster and the areas surrounding the bread slots become very hot during use, do not touch the heating elements, operating the toaster should be carried out using only the plastic dials and handles.
25. Do not move the toaster while in operation.Only after the toaster has completely cooled down should you attempt to move or handle it.
26. Do not cover the toaster while it is in use, never leave the toaster unattended during use.
27. Do not connect the toaster to an external timer to avoid danger.
28. Oversize foods, metal foil packages, or utensils must not be inserted in a toaster as they may involve a risk of fire or electric shock.
29. Bread is a food which may catch fire, A fire may occur if toasters are covered or touching flammable material, including curtains, draperies, walls, and the like, when in operation. Do not store any item on top of the toaster when in operation.
30. Do not attempt to dislodge food when toaster is plugged in.
31. When heating toaster pastries, always use the lightest toast color setting.
32. Never re-toast the same piece of bread at the same setting. If you wish to re-toast the bread, set the toasting control dial to a lower setting and do not leave the toaster unattended. Failure to do so may result in a fire hazard.

33. Do not clean with metal scouring pads. Pieces can break off the pad and touch electrical parts involving a risk of electric shock.
34. When the toaster is plugged into the electrical outlet or while it is turned on, never place hands in the bread toasting slots. Do not touch the toaster with wet or damp hands
35. Children should be supervised to ensure they do not play with the toaster. Cleaning and maintenance should not be carried out by children under 8 years old or unsupervised.
36. The plastic bag in which the toaster was packaged should be kept out of reach of children as it poses a suffocation hazard. In order to remove the dust that may have accumulated on the toaster, simply dust it off with a soft cloth.
37. Before connecting the product to power, check if the voltage indicated on the toaster matches the local power supply voltage.
38. Never wrap the cord tightly around the toaster during use or storage, this may cause the wire to fray and break.
39. The use of an extension cord is not recommended, as overheating of the extension cord may occur during operation of the toaster.

SAVE THESE INSTRUCTIONS

ADDITIONAL SAFEGUARDS

Polarized plug
This appliance has a polarized plug (one blade is wider than the other). To reduce the risk of electric shock, this plug is intended to fit into a polarized outlet only one way. If the plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to modify the plug in any way.

Short-cord instructions
A short power-supply cord (or detachable power-supply cord) is provided to reduce the risk resulting from becoming entangled in or tripping over a longer cord. Longer detachable power-supply cords or extension cords are available and may be used if care is exercised in their use.

Extension cords
If a longer detachable power-supply or extension cord is used:
1. The marked electrical rating of the cord set or extension cord should be at least as great as the electrical rating of the appliance.
2. The cord should be arranged so that it will not drape over a countertop or tabletop where it can be pulled on by children or tripped over unintentionally.
3. If the appliance is of the grounded type, the cord set or extension cord should be a grounding-type 3-wire cord.
4. Do not operate the appliance if the power cord shows any damage or if the appliance works intermittently or stops working entirely.

PRODUCT INTRODUCTION

Before using this product, please read this user manual carefully and follow the precautions, safety measures, warnings, and operating instructions inside, and keep it properly for future reference.



01		4-Slice Wide Toaster Slots
02		Loading lever (Toaster start-up)
03		Menu Function Display Area
04		Browning Color Display (1-6)

05		Browning Setting & Countdown Timer
06		L Cancel Button/ Mute Mode Button
07		Browning Time Decrease Button/ Browning Time Increase Button
08		LEFT side bread slot control button (Display after pressing down one side's loading lever)Increase Button RIGHT side bread slot control button (Display after pressing down one side's loading lever)
09		Defrost Button (Toast Function)
10		Bread Type Button
11		Reheat Button (Toast Function)
12		R Cancel Button / Cancel or Activate Standby Mode Button (press about 2s can turn off the display)
13		Crumb Tray

TOAST TIME

This product is designed to bake four slices of bread at the same time, if you only bake a piece of bread, please use 1st browning color setting to avoid burned.
The menu function is designed to toast, defrost or reheat (in conjunction with the toast function setting selection) various bread types, some bread types require more or less toast time due to many factors such as sugar content and density. Select your bread type for recommended toast time for ultimate results and be lit solid during toasting on the LED display.

TOAST TIME ±10S / BREAD TYPE	SETTING 1 (S)	SETTING 2 (S)	SETTING 3 (S)	SETTING 4 (S)	SETTING 5 (S)	SETTING 6 (S)
BREAD	70	120	150	180	210	230
BREAD + DEFROST	84	144	180	216	252	276
BREAD + REHEAT	30	30	30	30	30	30
BAGEL	100	140	180	220	260	300
BAGEL + DEFROST	120	168	216	264	312	360
BAGEL + REHEAT	30	30	30	30	30	30
PASTRY	65	85	105	125	145	170
PASTRY + DEFROST	78	102	126	150	174	204
PASTRY+REHEAT	30	30	30	30	30	30
GRAIN	70	95	120	145	170	195
GRAIN + DEFROST	84	114	144	174	204	234
GRAIN+REHEAT	30	30	30	30	30	30
EN MUFFIN	100	135	170	205	240	280
EN MUFFIN + DEFROST	120	162	204	246	288	336
EN MUFFIN + REHEAT	30	30	30	30	30	30
WAFFLE	70	95	120	160	185	210
WAFFLE + DEFROST	84	114	144	192	222	252
WAFFLE + REHEAT	30	30	30	30	30	30

OPERATION INSTRUCTION

This appliance is intended for household use.

Use on Alternating Current (120V~ 60 Hz) only for toaster.
Note: Do not tamper with any settings of the product.

This toast is for use on a circuit having a nominal rating of 120 volts and is factory equipped with a specific electric cord and plug to permit connection to a proper electric circuit. Make sure that the appliance is connected to an outlet having the same configuration as the plug. No adapter should be used with this appliance. Do not modify the plug provided; if it will not fit the outlet, have the proper outlet installed by a qualified electrician. If the appliance must be reconnected for use on a different type of electric circuit, the reconnection should be made by qualified service personnel.

Instructions for use

Before the first use:

1. After unpacking the appliance, check for transport damage and that all the parts mentioned in this manual are present. In the event of damaged or missing parts, return the product back to after-sales.
2. The plastic bag in which the appliance was packaged should be kept out of reach of children as it poses a suffocation hazard. In order to remove the dust that may have accumulated on the appliance, simply dust it off with a soft cloth.
3. Do not discard the original box. It can be used for storage and dispatch to avoid transport damage.
4. Before use, make sure that all the product's packaging material has been removed.
5. Before inserting the plug into the electrical outlet, make certain that the voltage of the outlet corresponds to the value indicated on the information label that is attached to the appliance.
6. Ensure the appliance and all parts are clean and dry before each use.
7. Some parts of the appliance have been lightly greased. Consequently, the first time the appliance is used a light smoke may be detected. After a short time, this smoke will disappear.

How to use your toaster

Note: before the first time to use, you can make a heating cycle without food for burn off any lubricants from the Artisan Toasty Slice heating elements and remove some smoke and smell.

1. Place the product on a stable, level, and flat surface. Do not place the product on a heat-sensitive surface.
2. Unwind the power cord. Check that the crumb tray (13) is in place and that there is nothing in the toaster slot (1). Plug into the power sock
3. After plug into power, The LED display will light up and the appliance will enter its standby default setting. Standby default setting will illuminate a flashing light on toaster setting "shade" and menu functions setting area.
4. Press the "BREAD TYPE" button (10) until the LED Display emits a flashing light on your desired bread type. Bread type settings include: BREAD, BAGEL, PASTRY, WAFFLE, EN MUFFIN (English Muffin), GRAIN.
5. Select desired Toast and Shade. Use the decrease ⏪ or increase ⏩ buttons to adjust to the desired shade.
6. Put your prepare food, likes bread, bagel, pastry, waffle, En muffin, grain inside the toaster slots (1), then pressing the loading lever (2) down fully until a "click" is heard to start the toaster.
7. The LED display will show your selected function, menu and toast time settings and setting light swill flash repeatedly from the first till the selected one and the toast time functions begin the countdown with the timer.
8. The loading lever (2) will pop up automatically once the timer has finished.
9. Always unplug the product after use.

REMARK:
LEFT (6) & RIGHT (12) Button
LEFT or RIGHT buttons will be displayed only after pressing down the loading lever(s)(2).
One side being browning process, can be set another side's browning function:

1) When right side being browning process, press the LEFT button (6) to set left side's browning function, then press down the loading lever (2) to start left side's browning process;
2) When left side being browning process, press the RIGHT button (12) to set right side's browning function, then press down the loading lever (2) to start right side's browning process.

Two sides being browning process, check the working status;

1) Press LEFT button (6) to check left side's working status;
2) Press RIGHT button (12) to check right side's working status;
3) Press the LEFT & RIGHT buttons together, screen will show each side's working status in turn. (Press either LEFT or RIGHT button to cancel this status).

Defrost function

The defrost function generates 20% longer browning time cycle perfect for toasting frozen bread types.

1. Press the "DEFROST" button (9) repeatedly until the LED display emits a flashing light on 'DEFROST'.
2. Select the bread type in the "BREAD TYPE setting (10).
3. A recommended browning time for the frozen bread type selected in the Menu setting will be suggested.
4. Press the loading lever (2) down fully.
5. The LED display will show your selected function, Menu and Browning Time settings and begin the countdown with the timer.
6. The toast will raise automatically once the timer has finished.

Reheat function

The reheat function is designed to reheat bread types after the toasting cycle has finished. The reheat function gives 30 seconds toast time for a burst of heat.

1. Press the "REHEAT" button (11) repeatedly until the LED display emits a flashing light on 'REHEAT'.

NOTE: shade screen will display words of "REH" after selection, in this function, the bread type and browning
time settings cannot be selected. When you need to exit it, press the reheat function button (11) again.

2. Press the loading lever (2) down fully.
3. The toast will raise automatically once the timer has finished.

Bagel function

The bagel function is designed to toast the bread by one side of the bread only. Only the toaster's outer heating coils are activated, the inner coils remain cold.

1. Press the "BREAD TYPE" button (10) until the LED Display emits a flashing light on 'BAGEL'.
2. Select desired Toast Function and Browning Time.
3. Press the loading lever (2) down fully
4. The LED display will show your selected Function, Menu and Browning Time settings and begin the countdown with the timer.
5. The toast will raise automatically once the timer has finished.

L cancel function

In the Operational State: To stop left side toast at any time during the browning process, press the "L cancel" button (6)

Mute mode function

In a Non-operational State: To activate or to cancel the mute mode, long press the "L cancel" button (6) for 2 seconds until one sound alert.

NOTE: all the sound alert would be canceled after activating the mute mode.

R cancel function

In the Operational State: To stop right side toasting at any time during the browning process, press the "R cancel" button (12).

Standby mode function

In a Non-operational State: To activate or to cancel the standby mode, long press the "R cancel" button (12) for 2 seconds.

NOTE: all the illumination except the R cancel light would be went out after activating the standby mode.

NOTE: Press any select function button can be exit the standby mode.

Crumb tray

- The crumb tray (13) should be emptied regularly as a build-up of crumbs could be a potential fire hazard. After toasting, let the toaster cool down thoroughly, then slide out the crumb tray and empty.
- Never operate the toaster without the crumb tray in place.

USER-MAINTENANCE INSTRUTIONS

1. Your appliance is virtually maintenance free. It contains no user serviceable parts and no lubrication is needed.
2. If any malfunction occurs, unplug the appliance, allow it to cool and Contact Seller services
3. Keep product surface clean and free of dust, dirt and hairspray
4. Allow the appliance to cool, and store it in a safe, dry location.
5. Do not wrap the cord around the toaster since this will cause the cord to wear prematurely and break. Use the cord storage cleats on the underside of the toaster, if the cord becomes twisted, untwist it prior to use.
6. Never allow the power supply cord to be pulled, twisted or severely bent. Inspect the cord frequently for damage. Stop use immediately if damage is visible, if the unit stops or if it operates intermittently.
7. Do not attempt to repair the appliance yourself.
8. WARNING: If any malfunction occurs, do not attempt to repair. This appliance has no user-serviceable parts.

CLEANING INSTRUCTIONS

These are the steps and precautions for cleaning the toaster to ensure that the product remains clean for the next use.

1. Before cleaning, switch off the toaster and unplug the power plug and let the product cool down. Do not clean the appliance while it is still working.
2. To remove any pieces of bread remaining in the toaster, turn the toaster upside down and gently shake. Never insert any hard or sharp instruments into the slot, as this could damage the toaster and cause a safety hazard.
3. Removing and empty the crump tray regularly after use. wipe with damp cloth, dry. then replace it in the toaster.
4. Do not use abrasive cleansers. Simply wipe the exterior with a clean damp cloth and dry thoroughly. Apply any cleansing agent to a cloth, not to the toaster, before cleaning.
5. DO not wash the main body in water, wipe the inside and outside of the product with a soft and damp cloth carefully. Avoid water or other liquids entering the product during cleaning or wiping the product surface.
6. Make sure the appliance is completely dry before using again.

Note: Remember not to use scouring powders, steel wool pads or other abrasive materials, metal utensils or abrasive cleaning materials to avoid damaging the product surface.

TO STORAGE

- When not in use, unplug the product and make sure it is completely cool before storing it.
- Your appliance should be disconnected and make sure the appliance is completely dry, then stored in a safe, dry location, out of reach of children.
- If the appliance is not used for an extended period, store it preferably in its original packaging.
- Do not wrap the cord around the toaster since this will cause the cord to wear prematurely and break, use the cord storage cleats on the underside of the toaster
- Handle cord carefully for longer life and avoid jerking, twisting or straining, especially at plug connections.

DISPOSAL INFORMATION



Electrical waste products should not be disposed of with household waste. Please recycle where facilities exist. Check with your local authority for recycling advice.