

Operation & Temperature Control [details refer to user manual]

ON/OFF



Hold ⏻ 3 seconds
to turn on or turn off

MAX/ECO Switch



Hold ❄ 3 seconds
to switch MAX/ECO

If there is any problem with the operation or use of the product, please feel free to contact us


18924140684
18924140684
Bougerv@gmail.com
https://www.bougerv.com/

Temp Control



Touch ∧ to + Temp
Touch ∨ to − Temp
Keep holding to fast adjustment

°F / °C Switch



Hold ∧ and ∨
together 3 seconds
to switch °F and °C