Before You Start, Download the Yale Secure App

Follow the steps on the back of this guide after you install your Yale Assure Lock®

Yale Secure app

Download on the App Store

Note: This lock is not for use with the Yale Assure app

Yale Customer Service: 1-855-213-5841

Yale® and Assure Lock® are registered trademarks of Yale Security Inc., an ASSA ABLOY Group Company.
Other products' brand names may be trademarks or registered trademarks of their respective owners and are mentioned for reference purposes only. © Copyright 2018. Yale Security Inc., an ASSA ABLOY Group Company. All rights reserved.
Reproduction in whole or in part without the express written permission of Yale Security Inc. is prohibited.
YA-SA-FLYER

An ASSA ABLOY Group brand



ASSA ABLOY

Get Started

Yale

Works with Apple HomeKit

1. Install your lock

Follow the printed installation manual in the box for instructions on how to install your Yale Assure Lock®. You can view 3D, interactive instructions on your smartphone or tablet by downloading the BILT app and searching for your Yale lock.

2. Turn on Bluetooth®

After installing your lock and downloading the Yale Secure app, go into your iPhone or iPad settings and ensure Bluetooth is turned on.

3. Install the module

Now, install your Yale iM1 Network Module:

- Remove the battery cover and batteries
- Insert the iM1 Network Module, with its visible pins in the bottom right corner, into the slot above the battery compartment
- Reinstall batteries and battery cover
- Enter your **master pin code** followed by ⚙
- Press **7**, followed by ⚙
- Press **1**, followed by ⚙

4. Create your home

Open the Yale Secure app and create a new home by tapping the **+** icon in the top right corner.

5. Add a lock

Tap the **+** icon next to your home name to add a new lock. Tap the Yale lock when it appears as an available device. Using your iPhone® or iPad®, scan the 8-digit Accessory Set-Up Code located on the back of your iM1 Installation Manual (inside the Network Module box). You can also manually enter this code in the app.

6. Name your lock

This is the name you'll use for Siri® commands so choose something simple like "Front Door".

Lock and unlock from anywhere!

When you have an Apple TV® (4th Gen or later) or iPad® (iOS 10.3 or later) set up as a home hub, you can lock and unlock your door, manage pin codes and receive notifications from anywhere! Visit YaleHome.com/iM1RemoteAccess for steps.

