iFFALCON

Hi! Let's get started.



55/65/75/85F75

DO NOT RETURN TO STORE

WE ARE READY TO HELP

contact us first with any questions



iFFALCON SUPPORT:
support.iffalcon.com/us
1-888-386-0077



TAKE CARE WHEN REMOVING THE TV

Important Information

CAUTION
RISK OF ELECTRIC SHOCK.
DO NOT OPEN.

This symbol indicates that this product incorporates double insulation between hazardous main voltage and user accessible parts. When servicing, use only identical replacement parts.

CAUTION: Neutral fusing. Disconnect mains before servicing.
Caution: To reduce the risk of electric shock, do not remove cover (or back). No user serviceable parts inside. Refer servicing to qualified service personnel.

This symbol indicates "dangerous voltage" inside the product that presents a risk of electric shock or personal injury.

This symbol indicates important instructions accompanying the product.

WARNING
To reduce the risk of fire or electric shock, do not expose this product to rain or moisture. This product should not be exposed to dripping or splashing. No objects filled with liquids, such as vases, should be placed on the apparatus.

WARNING
The TV is unstable if it is not properly attached to the base or mounted to the wall. Please follow the base or wall mounting instructions provided in the User's Guide to ensure your safety.

Warning: The batteries should not be exposed to excessive heat, such as prolonged direct sunlight, open flame, or fire of any kind. Refer to the identification/rating label located on the back panel of your product for its proper operating voltage.

Cable TV Installer: This reminder is provided to call your attention to Article 820-40 of the National Electrical Code (Section 54 of the Canadian Electrical Code, Part 1) which provides guidelines for proper grounding and, in particular, specifies that the cable ground should be connected to the grounding system of the building as close to the point of cable entry as practical.

Important: This television is a table model and is designed to sit on a firm, flat surface. Do not place the TV on soft carpeting or on a similar surface as this may cause the ventilation slots located on the bottom of the unit to be blocked and may result in reduced product lifespan from overheating. To assure adequate ventilation for this product, maintain a spacing of one (1) inch from the top and side of the TV receiver and two (2) inches from the rear of the TV receiver and other surfaces.
Make sure the TV stand or base you use is of adequate size and strength to prevent the TV from being accidentally tipped over, pushed off, or pulled off. This may cause personal injury and/or damage the TV. Refer to the Important Safety Instructions on the next page.
The Power button ⏻ on this TV and your remote control puts the TV into a very low-power standby mode but will not completely turn the power off. In order to completely shut the power off, you will need to disconnect the power cord from the outlet. The mains plug/appliance coupler is used to completely turn off the device. If you prefer to completely turn off the device, you should install the TV in a manner that allows you to disconnect the power cord when desired.

Product Information

Keep your sales receipt to obtain warranty parts and service and for proof of purchase. Attach it here and record the serial and model numbers in case you need them. These numbers are located on the product.
Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. Keep the apparatus at least 8 inches away from the human body.

Input	Signal Compatibility
Antenna/Cable	480i, 480p, 720p, 1080i (NTSC, ATSC, and QAM formats)
Composite Video	480i
HDMI	480i, 480p, 720p/60Hz, 1080i/60Hz, 1080p/60Hz, 2160p/24/30/60Hz

For the best viewing experience, remove the energy guide label from the TV front panel or TV screen before use.

Model No. _____ **Serial No.** _____


Purchase Date _____ **Dealer/Address/Phone** _____

Important Safety Instructions

1. Read these instructions.
2. Keep these instructions.
3. Heed all warnings.
4. Follow all instructions.
5. Do not use this apparatus near water.
6. Clean only with a dry cloth.
7. Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
8. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
9. Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
10. WARNING: Please refer the information on exterior bottom enclosure for electrical and safety information before installing or operating the apparatus.
11. WARNING: The main plug is used to disconnect the device and should remain readily operable.
12. When not in use, tie up the power cordset with a cable tie or with something similar. It should not be near sharp edges as it may cause abrasion of the power cordset. When put into use again, please make sure the power cordset is not damaged. If any damage is found, please use a replacement power cord specified by the manufacturer or that is identical to the original one.
13. No open flame sources, such as lit candles, should be placed on, under, or near the apparatus.
14. Unplug this apparatus during lightning storms or when unused for long periods of time.
15. Only use attachments/accessories specified by the manufacturer.
16. Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid any injury.



17. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
18. For safe operation of the apparatus, please follow these installation requirements:
    Keep at least 2 inches of ventilation space between the rear cover of the apparatus and the wall. Keep at least 1 inch of ventilation space between the apparatus and all other surfaces. Do not allow any of the apparatus' ventilation openings to be blocked by objects that might obstruct them, such as newspapers, curtains, table-cloths or any other objects. Do not expose the apparatus to any external heat sources. Do not place any heat sources such as candles, lamps, etc. on the apparatus. Do not expose the device to high levels of humidity or to any possible sources of moisture. When disposing of used batteries from the remote control, consult local regulations regarding proper disposal.
19. If an outside antenna or cable system is connected to the product, be sure the antenna or cable system is grounded so as to provide some protection against voltage surges and built-up static charges. Section 810 of the National Electrical Code, ANSI/NFPA No. 70-2011 (Section 54 of Canadian Electrical Code, Part 1) provides information with respect to proper grounding of the mast and supporting structure, grounding of the lead in wire to an antenna-discharge unit, size of grounding conductors, location of antenna discharge unit, connection to grounding electrodes, and requirements for the grounding electrode. See following example:



FCC Information

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This Class B digital apparatus complies with Canadian ICES-003.
The series, include models (55/65/75/85F75)
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.
Supplier Name: TTE Technology, Inc.
Supplier Address: 189 Technology Drive, Irvine, CA 92618, USA
Supplier phone number and internet contact information: 1-888-386-0077 support.iffalcon.com/us

Battery CAUTION & Disposal Information


1. For best results, use alkaline-type batteries.
2. Do not mix Alkaline, Standard (Carbon-Zinc), or Rechargeable (Nickel Cadmium or Nickel Metal Hydride) batteries.
3. Always replace depleted batteries with two same brand-new batteries from the same manufacturer. Never use damaged batteries.
4. Do not use Rechargeable (Nickel Cadmium or Nickel Metal Hydride) batteries.
5. Install only new batteries of the same type in your product. There is a risk of fire or explosion if the battery is replaced by an incorrect type.
6. Do not mix old and new batteries.
7. Batteries should not be exposed to excessive heat, such as prolonged direct sunlight, open flame, or fire of any kind as it may result in an explosion, or leakage of flammable liquid, or gas.
8. Batteries should not be exposed to extremely low air pressure as it may result in an explosion or the leakage of flammable liquid or gas.
9. Failure to insert batteries in the correct polarity, as indicated in the battery compartment, may shorten the life of the batteries or cause batteries to leak.
10. Batteries should be recycled or disposed of as per state and local guidelines. Do not dispose of batteries in a fire, hot oven, or mechanically crushing or cutting a battery, which may result in an explosion.

ELECTRONICS & PACKAGING RECYCLING INFORMATION

For information on recycling your old TVs, sound bars, and home comfort products, and to find drop-off locations in your area, please visit the “Electronics Recycling” area of the iFFALCON website at **support.iffalcon.com/us.** Click on our convenient interactive map to quickly locate a solution in your community. iFFALCON encourages consumers to always look for a recycling or reuse alternative to discarding televisions and other electronics, and in many areas iFFALCON has programs for consumers to drop-off and recycle televisions free of charge.
Look for convenient How2Recycle® labels on the product box for help preparing your new TV packaging for recycling. These labels show important information identifying the various types of packaging material included with your new TV along with easy-to-understand recycling instructions.

Warning: To avoid the danger of suffocation, keep plastic packaging away from babies, children, and pets. Do not use packaging bags in cribs, beds, carriages, or playpens.

What's in the box



iFFALCON TV



Power cable



2 x AAA batteries for remote



M5X18mm

6 x Stand screws





Table stands




2 x Screw hole covers




2 x Rubber protectors



Wall mount bracket




Quick Start Guide




TV remote


What you need



Phillips head screwdriver

Make the most of your TV





Router + Internet Connection (needed for streaming)

For additional support, please visit support.iffalcon.com/us

Step 1 Set up your TV

Ready for the step-by-step? You're only minutes away from TV bliss!


Warning: To avoid the danger of suffocation, keep plastic packaging away from babies, children, and pets. Do not use packaging bags in cribs, beds, carriages, or playpens.

Remove TV from box

Be careful, it's heavy!

Rubber Protector Installation

Note: Before hanging the TV on the wall, please press the rubber protectors onto the position shown in the illustration.




Wall Mount Installation

Note: Please follow the Wall Mount Bracket Installation Guide in the Wall mount bracket box to finish the installation.


Table Stand Installation

Note: Two professionals are required to perform the below steps.

1. To prevent damage to the screen, carefully place your TV on a soft, cushioned surface. Please make sure that the surface must larger than the TV.
2. Align the stands with screw holes and locating holes in the high or low position on the TV. Secure the stands to the TV with six (6) screws.
3. Slide the screw hole covers and install the magnetic decorative cover.
4. All installation is now completed.



The black holes are screw holes while the white holes are locating holes.The table stands can be installed in a high position or low position. See figure above.



Note:
Dust may be attracted to the magnet area on the back cover. This is a normal phenomenon and the dust can be removed by wiping.

Warning (Stability Hazard):

Never place a television set in an unstable location. A television set may fall, causing serious personal injury or death. Many injuries, particularly to children, can be avoided by taking simple precautions such as:

- Using cabinets or stands recommended by the manufacturer of the television set.
- Only using furniture that can safely support the television set.
- Ensuring the television set is not overhanging the edge of the supporting furniture.
- Not placing the television set on tall furniture (for example, cupboards or bookcases) without anchoring both the furniture and the television set to a suitable support.
- Not placing the television set on cloth or other materials that may be located between the television set and supporting furniture.
- Educating children about the dangers of climbing on furniture to reach the television set or its controls.
- NEVER place items that might encourage children to climb, such as toys and remote controls, on the top of the television or furniture on which the television is placed.
- ALWAYS route cords and cables connected to your television so they cannot be tripped over, pulled or grabbed.

If your existing television set is being retained and relocated, the same considerations as above should be applied.


Step 2 Power up

In this step, we'll make sure all systems are a GO!

Connect your power cable to the TV, then plug it into the wall outlet.

Power your TV remote by inserting the included batteries.

If applicable, connect external devices by referencing port label and descriptions on Page 9.



Insert batteries in the correct polarity as indicated in the battery compartment.

Power Tip! Always replace depleted batteries with two same brand-new batteries from the same manufacturer. Never use damaged batteries.

If your remote gets warm/hot during use, discontinue use and contact customer support immediately at support.iffalcon.com/us.

Review the Battery CAUTION & Disposal Information on page 3.

Step 3 Grab your remote

The TV remote should feel right at home in your hand. We designed it to be incredibly intuitive for watching TV and navigating on-screen menus.

INPUT To select input source and display the quick panel

REMOTE MICROPHONE Talk to the remote microphone after pressing the Google Assistant button

POWER Turn TV on and off

PROFILE SELECTOR Switch profile

GOOGLE ASSISTANT BUTTON Press to activate the remote's Google Assistant microphone. Search content through your voice by holding down the button.

SETTINGS To display the dashboard menu

CIRCULAR D-PAD Navigation direction buttons (Up/Down/Left/Right)

OK BUTTON To confirm an entry or selection

BACK Return to previous screen

HOME To access the TV homepage

LIVE GUIDE Open live TV EPG

VOLUME Raise and lower volume

CHANNEL To change channels


QUICK SETTINGS Open the quick menu

MUTE Press the button to mute the sound

TCL HOME To access TCL Home.


VIRTUAL KEYBOARD Open virtual keyboard on screen

INFORMATION In TV source, press to view the program information



Tip! Follow the on-screen guide to pair the remote control with the TV when pressing the button for the first time.

Step 4 Get to know your TV




A **STATUS LIGHT** Glows when the TV is in standby.

IR RECEIVER Receives signal from the TV remote.

POWER and OPTIONS BUTTON Press the button to turn the TV on/off, or select the menu.

***The IR receiver/indicator is adjustable to a high or low position and may slightly move when pressed.**



B **POWER PORT** Connect your TV to the power source with theincluded power cable.

C **USB PORT** Connect a USB device to access photos, music and movies.

D **LAN** Connect using a lan cable to your home network router or switch.

E **HDMI (e)ARC PORT** Connect HDMI eARC/ARC (audio return channel) capable audio devices like sound bars or AV receivers.

F **HDMI® PORT** Highest quality audio/video connection. Connect cable box, Blu-ray player, gaming console, or other devices to your TV using HDMI cables.

G **ANTENNA/CABLE IN** Connect an outdoor VHF/UHF antenna or Cable TV feed.

H **AV IN adapter** AV Input (analog audio/video). The AV Input can be used to connect older devices that use analog audio/video outputs. Compatible adapter (not included) connects to the RCA cable (video - yellow and audio - white and red) that you normally use to connect to that device.

I **HEADPHONE OUT** Connect headphones or other external speakers.

J **OPTICAL (DIGITAL AUDIO OUT)** Connect an optical cable to an external digital audio system.

Step 5 Complete guided setup

It’s the final stretch-hurray!

Let’s Connect

Once your language has been selected, you can quickly set up the TV using the Google Home app on an Android or iOS phone.



TV interface may vary and is subject to change.
The model number shown will vary depending on your iFFALCON Google TV model number.

To enjoy all smart features and services on your iFFALCON TV with Google TV™, a free Google account, a free TCL account, and a reliable broadband internet connection, are required.

And setup is done... Congratulations!

Continue using the remote to personalize your Home screen, streaming apps line-up, stream movies, and so much more.

Key things to know:
A paid subscription or other payments may be required for some streaming apps. Streaming apps availability are subject to change and vary by country.

WE ARE READY TO HELP

contact us first with any questions

iFFALCON SUPPORT:
support.iffalcon.com/us
1-888-386-0077

LIMITED WARRANTY for iFFALCON Televisions

What Your Warranty Covers:

This warranty covers defects in materials or workmanship for the original owner of this iFFALCON product, provided it was purchased as new from an authorized iFFALCON dealer in the United States and comes packaged with this warranty statement.

Important: To ensure your newly purchased TV can be serviced if needed, please keep the original packaging materials and receipt. If a product is returned to iFFALCON for service without proper packaging, any damage incurred may void your warranty.

New Products (Non-Commercial Use):

Coverage lasts one (1) year from the date of purchase or delivery for parts and labor for non-commercial use.

New Products (Commercial Use)

Coverage lasts six (6) months from the date of purchase or delivery for parts and labor for commercial use. Commercial use includes, but is not limited to, usage in a business environment, institutional purposes, or rental purposes.

What We Will Do:

At iFFALCON's discretion, we will either:

- Pay an authorized iFFALCON Service Center for labor and parts to repair your product, or
- Replace your product with a new or refurbished equivalent.

The decision to repair or replace will be made solely by iFFALCON.

How to Get Warranty Service:

- Before requesting warranty service, visit support.iFFALCON.com for helpful setup and troubleshooting tips.
- Warranty service is obtained by contacting iFFALCON Customer Service using methods listed on support.iFFALCON.com/contactus. Make sure you have the product model number and serial number ready.
- Troubleshooting and prior approval from an iFFALCON representative is required before sending your product to an authorized iFFALCON Service Center and/or processing any warranty service claims.
- A representative will troubleshoot your product issue prior to service approval. If it is determined that your unit requires service, the service location will be at the sole discretion of iFFALCON, based on this limited warranty statement.
- For televisions 43 inches and smaller, repairs may occur at an authorized iFFALCON Service Center, or you may receive a direct exchange for a new or refurbished unit. For televisions 44 inches and larger, repairs may be conducted at a service center or in-home. If an on-site technician determines that the conditions are hazardous or unsafe, iFFALCON reserves the right to cancel or reschedule the service visit or opt for an exchange of the unit for a refurbished one instead of an in-home visit.
- iFFALCON is not responsible for transportation costs associated with warranty coverage, including the repair or replacement of units sent to an authorized service center. However, iFFALCON will cover return shipping to a U.S. address. Instructions for packaging and shipping will be provided. Units improperly packed and damaged during shipping are not covered under this warranty.
- Proof of purchase in the form of an original bill of sale or receipted invoice from an authorized dealer, with a legible date of purchase that evidences the Product is within the applicable warranty period must be presented obtain warranty service.
- If a unit needs to be replaced, you may be required to provide a picture of the back of the unit clearly showing the model and serial number, as well as a picture or video of the product issue.
- Pre-authorization must be obtained before (1) sending any product to an authorized iFFALCON service center or (2) obtaining any in-home repair, replacement, or refund.

LIMITED WARRANTY for iFFALCON Televisions

What Your Warranty Does Not Cover:

- Units sold in "As-Is," "Used," "Factory Reconditioned," "Factory Re-Certified," or "Refurbished" condition or with faults.
- Damage caused during transportation or handling, including shipping from the retailer. Please contact your retailer for assistance.
- Extended service plans purchased from retailers, please contact your retailer for assistance.
- Customer instruction. (Your Owner's Manual describes how to install, adjust, and operate your Unit. Any additional information should be obtained from your Authorized Dealer).
- Service calls to your home for delivery, installation, or pick-up, or for correcting unauthorized repairs.
- Any installation, delivery, setup, adjustment (including but not limited to wall mount) and/or programming charges.
- Installation and related adjustments, or damage resulting from installation.
- Damage resulting from non-approved installation or repair methods.
- Failure of the Product to perform due to signal reception problems not caused by your Unit, or due to power failures or interruptions, or inadequate electrical service.
- Damage from misuse, abuse, neglect, insects, normal wear and tear, cosmetic damage, mishandling, faulty installation, inadequate electrical wiring, or power line surges.
- Damage caused by operating the Product in a corrosive or wet atmosphere.
- Any issues with signal reception (including antenna-related problems), markings or images on the television's panel resulting from viewing fixed images (including but not limited to certain 4:3 images on wide screen televisions images "burned" onto the screen, signal noise or echo, interference, or other problems with signal transmission or delivery, as well as the availability of third-party services or content (including but not limited to image, audio, or video content).
- Units that have original factory serial numbers that are unreadable or missing, or that have been changed, defaced, or altered in any manner.
- Batteries.
- A television that has been modified or incorporated into other Products, or that has had the serial number removed or altered.
- Use of accessories or components that are not compatible with this Product.
- A Unit purchased or serviced outside of the United States.
- Costs of shipping the Unit to the Authorized IFFALCON Service Center or IFFALCON-designated address. IFFALCON will pay for return shipping to the customer to a United States address only.
- Acts of nature or God (as illustrative examples and for the avoidance of doubt, such acts of nature or God include but are not limited to damage caused by earthquakes, fires, lightning, or flood whether caused by nature or humans).
- Special, incidental, or consequential damages.

Limitation of Warranty:

This warranty is the only warranty applicable to this product. No verbal or written information provided by TTE Technology, Inc., its agents, or employees will create any guarantee or modify the scope of this warranty in any way. Repair or replacement under this warranty is the exclusive remedy for the consumer.
TTE Technology, Inc. is not liable for special, incidental, or consequential damages arising from the use of this product or any breach of express or implied warranty. This disclaimer and limited warranty are governed by the laws of the state of California. Except as prohibited by law, any implied warranty of merchantability or fitness for a particular purpose is limited to the warranty and warranty period specified above. This warranty is subject to change without notice. Please visit www.iFFALCON.com for the most current version.

How State Law Relates to This Warranty:

Some states may not allow the exclusion or limitation of incidental or consequential damages, or limitations on how long an implied warranty lasts, so the above limitations or exclusions may not apply to you. This warranty provides specific legal rights, and you may also have other rights that vary from state to state.

If you purchased your unit outside of the United States or seek warranty service coverage outside of the United States, this warranty does not apply. Contact your dealer for warranty information. Service calls not involving defective materials or workmanship are not covered by this limited warranty, and the costs of such service calls are the sole responsibility of the purchaser.

Broadcasting & Operating Environment

Broadcasting system	US System NTSC-M ATSC standard (8VSB), QAM
Receiving Channels	VHF2-13 UHF14-69 CATV 14-36 (A)-(W) 37-59 (AA)-(WW) 60-85 (AAA)-(ZZZ) 86-94 (86)-(94)95-99 (A-5)-(A-1) 100-135 (100)-(135) 01 (4A)
Tuner type	Frequency synthesized
Operating Temperature	5°C to 35°C (41°F to 95°F)
Operating Humidity	20% to 80%, non-condensing
Storage Temperature	-15°C to 45°C (5°F to 113°F)
Storage Humidity	10% to 90%, non-condensing

The terms HDMI, HDMI High-Definition Multimedia Interface, HDMI Trade Dress and the HDMI Logos are trademarks or registered trademarks of HDMI Licensing Administrator, Inc.

Dolby, Dolby Vision, Dolby Vision IQ, Dolby Atmos, Dolby Audio and the double-D symbol are trademarks of Dolby Laboratories Licensing Corporation. Manufactured under license from Dolby Laboratories. Confidential unpublished works. Copyright © 1992–2024 Dolby Laboratories. All rights reserved.

For DTS patents, see http://xperi.com/dts-patents/. Manufactured under license from DTS, Inc. and its affiliates. DTS, DTS:X, the DTS:X logo, Virtual:X, and the DTS Virtual:X logo are registered trademarks or trademarks of DTS, Inc. and its affiliates in the United States and/or other countries. © DTS, Inc. and its affiliates. ALL RIGHTS RESERVED.

Covered by one or more claims of the HEVC patents listed at patentlist.accessadvance.com.

Note:
Figures and illustrations in this QSG are provided for reference only and may differ from actual product appearance. Product design and specifications may be changed without notice.

Troubleshooting

Having trouble completing the guided setup? Don't worry, it's usually an easy fix.

Cannot connect to wireless network (WiFi)

- Select the correct wireless network name and verify the password entered (case sensitive).
- Relocate the router from objects that interfere with performance (cordless phones, baby monitors, etc.).
- Reboot the router by disconnecting the power for more than 2 minutes and reconnect.

Problems connecting my cable box or antenna through a coax cable

- For best performance, use the HDMI connection. If not available, then:
- Make sure the cable connections to the TV and your device are securely fastened.
- Select cable or antenna input.
- Select the channel scan menu and follow the on-screen instructions to perform a full channel scan.

Access parental control

- Select "Settings" from the home screen.
- Select "System".
- Select "Parental Controls" to set up or change your personal password.

Notes:

- You can set up your personal password anytime.
- If you forget your personal password, you can use 0423 to reset.

How to use voice control through the remote control?

- In Google TV mode, press and hold the "HOME" and "OK" buttons on your remote at the same time.
- Keep your remote within 3 ft. of your TV during the pairing process.
- Then, when the TV display shows that the Google Assistant is ready – speak towards the remote microphone by holding down the Google Assistant button to ask a question or try a suggestion.

Need more help?

support.iffalcon.com/us

1-888-386-0077

iFFALCON

Copyright © 2024 by iFFALCON. All rights reserved.
iFFALCON and the iFFALCON logo, as well as other brand and product names are the trademarks of their respective owners, under license to iFFALCON North America.

TTE Technology, Inc.
189 Technology Drive, Irvine, CA 92618, USA

J0104-000691