




HVX601
Premium Tilt 4D TV Mount
Installation Manual








To facilitate your installation, please refer to this installation guide.
Thank you for choosing HOME VISION! This product comes with 10 years warranty.
For any questions during installation and use, please contact us first. We are 7*24 hours available to ensure that your problems will be 100% well-solved.
Email: customerservice@homevisional.com
https://en.homevisional.com


●Before Installation:

1. Check the wall

Drywall with wood studs




Solid concrete or concrete block




CAUTION:
DO NOT install into pure drywall alone


2. Check your TV VESA pattern （VESA=Horizontal x Vertical）
Check the four holes at the back of your TV.




Please check the ports on the back of the TV to avoid potential clogging.




3. Please prepare these tools required for the installation



Tape Measure | Pencil | Awl | Screw Driver | Electric Drill | Socket Wrench



Stud Finder | Wood Drill Bit




Masonry Drill Bit | Hammer


●Package Included:

⚠ **WARNING:** Before assembling please confirm whether all accessories are packaged completely.
Do not swallow any accessories. Small accessories may cause choking hazard if swallowed.


Main parts




1 Velcro x3



2 Level x1



3 TV Bracket on the Left x1



4 TV Bracket on the Right x1




5 Wall Panel x1



6 Mounting Template x1

For wall drilling



A Tapping Screw (5/16*2.75'') × 4




B Anchor (ϕ10*60) × 4




C M8 Washer (¢ 22*8.5*2.0) × 4


For TV bracket installing




D M4*15 ×4




E M4*30 ×4




F M6*15 ×4



G M6*30 ×4



H M8*15 ×4




I M8*45 ×4



J M4/M5 Washer (¢16*6.0*1.0) ×4



K M6/M8 Washer (¢20*8.5*1.5) ×4



L 10mm Spacer Ring (¢18*8.5*10.0) ×8



M 5mm Spacer Ring (¢18*8.5*5.0) ×8




N Wrench ×1




O Allen Key ×1

● Installation Steps:


1. Select the right screws/washers/spacer rings according to the size and depth of the TV screw holes.






2. Install the TV panel

Combination of screws and washers





OR

Combination of screws, washers and spacer rings




2.1. Install the brackets








3. Install the wall panel


3.1 Wood studs
























3.2 Concrete/brick wall




















4. Hang the TV

4.1 Verify the firmness of the wall panel.




4.2 Hang the TV






5. Adjust the angle of your TV freely according to your preference

5.1 Slide and telescope parallel left and right.Swivel 8°±2° smoothly.
Tilt up +5° & tilt down -10°.



5.2 Horizontal ±4°adjustable. Advanced hover damper ensures your TV stay at the angle you need steadily.



Tips: When removing the TV, pull down the left and right drawstrings at the same time to avoid damaging the lock.

Made in China Rev.B