尺寸：184mmx58mm　105铜版纸　　四色印刷　过哑膜

正面

Fanttik

QUICK START GUIDE

Quick connect valve adapter

背面

Fanttik



Schrader valve: **8.5mm**

Presta valve: **4.5mm**

1.Seal part
2.Unique convertible valve
3.Pillar
4.Air chuck

1



Confirm whether the tire is a Schrader valve or a Presta valve before. If it is a Schrader valve, it needs to turn the valve [2&3] to another side. if it's a Presta valve, you could use it directly.

Fanttik

2



Connect the hose to tire inflator.

3



Open the state.

4





Ensure the air nozzle is fully connected to the bicycle valve before locking it back; a double tightening is recommended for security.