


Roku®
Select Series




What's included



Roku Select Series TV



TV power cord included for 50"- 85" models only



x 4 screws

Stand screws



TV stands




Roku TV Remote

What you need



Phillips head screwdriver




Laptop or mobile phone for activation



Internet connection

STEP 1: Set up your TV



A **Prepare a surface**

Put a soft covering like a blanket down onto a clean, flat surface (make sure it's larger than the TV) and place the TV on it.

B **Attach the stands**


Use a screwdriver and included screws to attach the stands.

C **Set TV upright**


Place your TV on a stable, flat surface.

Mounting your TV?

For instructions, skip these steps and visit **go.roku.com/tvmount**




STEP 2: Plug TV in and power your remote



A Connect your TV


Plug your TV into a power outlet. It should turn on automatically. If it doesn't, press the power button.



B Power your remote

See the remote features card on how to use your Roku TV remote.

STEP 3: Activate your TV



Connect your TV

Follow the instructions on your TV screen. Activate your TV by using your computer or smartphone to link a Roku account.

IMPORTANT
Roku never charges for activation support.

Frequently asked questions

Why do I need an internet connection?
You'll need an internet connection to set up your TV, stream your favorite channels and for automatic software updates.

Why should I enter a payment method?
Saving a payment method makes it easy to rent or buy movies, subscribe to popular channels, and start free trials in just a click. No charges will be made without your authorization.

Get to know your TV

HDMI - Game consoles, DVD players

Composite (available on some models) - Analog devices, older game consoles

Antenna/Cable - Digital antenna, cable connection

Audio connections

HDMI ARC or eARC (recommended) - AV receivers, soundbars

Optical (S/PDIF) - AV receivers, soundbars


Headphone Jack (available on some models) - Wired headphones

Other connections

USB - Flash drive for media playback

Ethernet (available on some models) - Wired internet connection

Roku Remote features



Power your remote
Includes pre-installed batteries. Pull out the tab on the back of your remote. It will pair to your TV automatically.

Voice search & control
Quickly search across thousands of apps, play entertainment, control your streaming, and more with your voice.

Find your lost remote
Use the Roku mobile app or press the TV's power button to bring up the options menu.

Live TV in a click
Start watching free live TV and local news with just one press.

Save your faves
Personalize shortcuts to open any app, turn on closed captions, and more with the quick launch button.


© 2026 Roku, Inc. All Rights Reserved. Roku, the Roku logo, and the purple d-pad and purple fabric tag designs are trademarks or registered trademarks of Roku, Inc.

Need help?

For setup help or support, visit or call

go.roku.com/TV

1-816-272-8106
4:00 am – 10:00 pm PT



Roku

© 2026 Roku, Inc. All Rights Reserved. Roku, the Roku logo, and the purple d-pad and purple fabric tag designs are trademarks or registered trademarks of Roku, Inc.

Manufactured under license from Dolby Laboratories. Dolby, Dolby Audio, and the double-D symbol are registered trademarks of Dolby Laboratories Licensing Corporation. Confidential unpublished works. Copyright 1992-2019 Dolby Laboratories. All rights reserved.