Lockset Enrollment Guide

Step by step instructions for adding your Kwikset lockset to your SmartThings, Iris, Wink, Xfinity or Cox system.

Z-WAVE

SmartThings


1. Launch app
2. Go to “My Home” tab
3. Tap “+” sign
4. Push “A” button on lock interior one time
5. Enter a name (if desired)
6. “Done”

Iris

1. Launch app
2. Tap "+" sign
3. Tap "Device"
4. Tap "Kwikset"
5. Tap the lock model
6. Tap “Next” three times
7. Push "A" button on lock interior one time

Wink

1. Launch app
2. Tap gear icon
3. Tap “Add new lock”
4. Tap “SmartCode Deadbolt by Kwikset”
5. Tap “Next” three times
6. Push “A” button on lock interior one time



HOME CONNECT™

Need more support?

kwikset.com/wirelesslocks
connected@kwikset.com • 866-863-6584

ZigBee®

SmartThings

1. Launch app
2. Go to “My Home” tab
3. Tap “+” sign
4. Push “A” button on lock interior four times
5. Enter a name (if desired)
6. “Done”

Iris

1. Launch app
2. Tap “+” sign
3. Tap “Device”
4. Tap “Kwikset”
5. Tap the lock model
6. Tap “Next” three times
7. Push “A” button on lock interior four times

Wink

1. Launch app
2. Tap gear icon
3. Tap “Add new lock”
4. Tap “SmartCode Deadbolt by Kwikset”
5. Tap “Next” three times
6. Push “A” button on lock interior four times

xfinity / COX

1. Begin enrolment at the panel
2. Tap “Settings”
3. Enter panel security code
4. Tap “Home Devices”
5. Tap “Door Locks”
6. Tap “Add Door Lock”
7. “Next”
8. Push “A” button on lock interior four times
9. “Done”
10. “Next”
11. Tap lock icon to assign friendly name
12. “Next”
13. “Return to Menu”