AC Plug Replacement Quick Guide

⚠Important Safety Warning


Please follow this guide strictly.Incorrect wiring may cause electric shock, fire, or equipment damage. Power off and disconnect all connections before use. If unsure, contact a qualified electrician.


240Vac Wiring Instructions (NEMA L14-30P)

The product comes pre-installed with a NEMA L14-30P 4-prong locking plug, suitable for 240V / 30A outlets.

When facing the plug with the pins toward you:

- **L-shaped pin (Ground) → connect to Green wire**
- **Bottom pin (L1) → connect to Black wire**
- **Top pin (L2) → connect to White wire**





120Vac Wiring Instructions (NEMA L5-30P)

When using a 120V / 30A outlet, replace the pre-installed plug with the included NEMA L5-30P 3-prong locking plug.

When facing the plug with the pins toward you:

- **L-shaped pin (G) → connect to Green wire**
- **Upper pin (N) → connect to White wire**
- **Lower pin (L) → connect to Black wire**

