
Quick Installation Guide

AC1750 Wireless Dual Band Gigabit Router
Archer C7

Connect the Hardware

If your internet connection is through an Ethernet cable directly from the wall instead of through a DSL/Cable/Satellite modem, connect the Ethernet cable to the router's Internet port, and then follow Step1, 5 and 6 to complete the hardware connection.



6 Verify that the following LEDs are on and solid to confirm the hardware is connected correctly.

Power	2.4GHz	5GHz	Internet
On	On	On	On (Green or Orange)

Note: If the 2.4GHz LED and 5GHz LED are off, press and hold the WPS/Wi-Fi button on the back for more than 2 seconds. Both the LEDs should turn solid on.


Configure the Cloud Router

Method ONE: Via TP-Link Tether App

1. Download the Tether app.

Download on the App Store
GET IT ON Google Play
or
Scan for Tether
Tether

2. Connect your smartphone to the router.



The default wireless network names (SSIDs) and password are printed on the label at the bottom of the router.


3. Connect the router to the internet.



A Launch the Tether app. Select **Archer C7** from the local device list.

B Create a login password and follow the steps to connect to the internet.

4. Register the TP-Link Cloud service.



To enjoy a more complete service from TP-Link, tap **Bind Now** when prompted and follow the instructions to register and bind a **TP-Link ID** to your cloud router.

With TP-Link ID, you can conveniently manage your home network from your smartphone or tablet via the Tether app, no matter where you find yourself.


Enjoy the internet !

Method TWO: Via Web Browser

1. Connect your device to the router (wired or wireless).

- **Wired**

Turn off the Wi-Fi on your computer and connect the devices as shown below.




- **Wireless**

a Find the SSID and wireless password printed on the label of the router.

©2017 TP-Link 7106507655 REV4.2.1

b Click the network icon of your computer or go to Wi-Fi settings of your smart device, and then select the SSID to join the network.




2. Connect the router to the internet.

A Launch a web browser, and enter **http://tplinkwifi.net** or **http://192.168.0.1** in the address bar. Create a login password and then click **Let's Get Started**.

Note: If the login window does not appear, please refer to **Q1** of **Need Help?** in this guide.




B Follow the step-by-step instructions to set up the internet connection and register the TP-Link Cloud service.



Enjoy the internet !

USB Applications

With the dual USB ports, it's easy to share printers, files and media with multiple devices.



Local Storage Sharing
Share files from the USB drive with devices on your home network

Printer Sharing
Share a printer with multiple computers connected to the router

Remote Access
Access the USB drive when you are away from home

Media Server
Play media from the USB drive on your computer and smart devices

To learn more about the USB applications, visit http://www.tp-link.com/app/usb, or simply scan the QR code.

TP-Link Cloud Service

TP-Link Cloud service provides a better way to manage your cloud devices. For example:



Remote Management
Easily manage your home network when you are out and about via the Tether app on your smartphone or tablet.

Timely Upgrade Notifications
Keep informed of the latest firmware updates, ensuring your router stays at its best.

One for All
Manage multiple TP-Link Cloud devices, all from a single TP-Link ID.

You can set up and enjoy cloud functions via the **Tether app** or through the web management page at **http://tplinkwifi.net**.

To learn more about TP-Link Cloud service and other useful features supported by the router (including Guest Network, Parental Controls, Access Control and more), please refer to the **User Manual** at **www.tp-link.com**.

Need Help?

Q1. What should I do if I cannot access the web management page?

- If the computer is set to a static IP address, change its settings to obtain an IP address automatically.
- Verify that **http://tplinkwifi.net** is correctly entered in the web browser. Alternatively, enter **http://192.168.0.1** or **http://192.168.1.1** in the web browser and press **Enter**.
- Use another web browser and try again.
- Reboot your router and try again.
- Disable and enable the network adapter being used.

Q2. What should I do if I cannot access the internet?

- Check if the internet is working normally by connecting a computer directly to the modem using an Ethernet cable. If it is not, contact your internet service provider.
- Log in to the web management page of the router, and go to the **Basic > Network Map** page to check whether the internet IP address is valid or not. If it is, please run the Quick Setup again; otherwise, check the hardware connection.
- Reboot your router and try again.
- For cable modem users, log in to the web management page of the router. Go to **Advanced > Network > Internet > MAC Clone**, click **Use Current Computer MAC Address** and click **Save**. Then reboot both the modem and the router.

Q3. How do I restore the router to its factory default settings?

- With the router powered on, use a pin to press and hold the **Reset** button on the back until the Power LED blinks.
- Log in to the web management page of the router, go to **Advanced > System Tools > Backup & Restore**, and click **Factory Restore**. The router will restore and reboot automatically.

Q4. What should I do if I forget my web management page password??

- If you are using a TP-Link ID to log in, click **Forgot password** on the login page and then follow the instructions to reset it.
- Alternatively, press and hold the **Reset** button on the back of the router until the Power LED blinks to reset it, then visit **http://tplinkwifi.net** to create a new login password.

Q5. What should I do if I forget my wireless network password?

- If you have not changed the default wireless password, it can be found on the label at the bottom of the router.
- Connect a computer directly to the router using an Ethernet cable. Log in to the router's web management page at **http://tplinkwifi.net**, and go to **Basic > Wireless** to retrieve or reset your wireless password.

For technical support and other information, please visit http://www.tp-link.com/support, or simply scan the QR code.