

ANCEL FX2000 Upgrade Guide

There are 2 methods to upgrade the FX2000 scan tool, method 1(Via TF Card) and method 2(Via USB Cable). Here's the upgrade guide following for method 2(Via USB Cable).


Step 1: Before starting the upgrade, please connect this device to a computer via the USB cable, and make network connection stable. (It supports WIN XP, 7, 8, 10 operating systems.)



Step 2: Link to ANCEL website (Register & Log in).
https://anceltech.com/account/register




Step 3: Download the update software on a computer.
https://anceltech.com/support/download




Step 4: Click the software and install the update tool.

(1)




(2)




Step 5: Find this software on your computer and open it.




Step 6: Select connection mode “USB” and click “OK” to continue. The "Product Serial Number" will be read automatically, then hit “Device Upgrade”.







Step 7: Move to the register page, type your email address and Register Code will be read automatically, then hit “Submit”.




Step 8: Choose “Select All” and click “Download” to start downloading.





Step 9: When the 2 progress bars reach 100%, the upgrade completes. Click “Quit” and disconnect the USB cable.



How to check if the FX2000 has installed the latest software?

Connect the FX2000 to a computer and open the update tool. If the local version is the same as the latest version, it has installed the latest version of the software.

