FOXWELL
Shenzhen Foxwell Technology Co., Ltd.

QUICK START GUIDE For Handheld Scanners

To Register Through Website



1. Visit Foxwell website www.foxwelltech.us and press **Register** icon, or go to the registration page by selecting **Support** from home page and then click **Register**.




2. Enter one of your email addresses as your user ID and click the **Send Code** button. We will send a 4-digit verification code to the email you just entered. Find the security code in your mailbox, input the code, create a password and click **Free Registration** to complete.




3. Sign in to the Member Center, click **New Registration**, input the right serial number and click **Submit** to activate the product.


To Register Via Update Client




1. Visit our site www.foxwelltech.us and then click **Support** at the home page. Click **Tools** at the support page and find the product you have to download the update client.




2. Unzip the file and find the installer to install the update client to your computer.



3. Click the desktop icon to launch the update client and click **Register** icon to create a Foxwell ID.



4. Enter one of your email addresses as your user ID and click the Send Code button. We will send a 4-digit verification code to the email you just entered.




5. Find the security code in your mailbox, input the code, create a password and click **Free Registration** to complete.



6. Sign in your Foxwell account and select **Activation.** Input a serial number or click the **Read** icon to read the SN from the scanner. Click **Activate** button to activate.

Vehicle Connection




1. Locate the data link connector(DLC) under the dash on the driver side of the vehicle.
2. Connect the diagnostic cable to the scanner and plug it to the vehicle DLC.
3. Switch the ignition key to the ON position.
4. Go to Main menu to choose diagnostic software to start test.

Serial Number

To find the serial number:

1. On the back of the main unit.



2. In the scanner Settings-About page.



Pictures illustrated here are for reference only and this Quick Start Guide is subject to change without prior notice. For more detailed operations, please refer to the User's Manual.

FOXWELL
Shenzhen Foxwell Technology Co., Ltd.

QUICK START GUIDE For Handheld Scanners

Diagnostic Operations

- Before start diagnosis, please make sure:
  1. The ignition switch is turned to ON position.
  2. The engine is off.
  3. The vehicle battery voltage is between 10-14 volts.
  4. The scanner is correctly connected to the vehicle.
- Don't connect or disconnect the equipments while the ignition is on or the engine is running.

1. Establish communication with the vehicle via diagnostic cable.
2. Identity the vehicle either by VIN reading or entering vehicle specifications manually.
3. Find the control modules installed in the vehicle either by Quick Scan or manual selection.
4. Start the tests and make records of test data when necessary.

Update


Before updating, please make sure you have created a Foxwell ID and your network works correctly.



1. Launch the update tool **FoxAssist** by double clicking the desktop icon and login with your Foxwell ID and password.



2. Connect the scanner to the computer with the USB cable provided.



3. Select **Download** then all the updates applicable to your tool display. Click the check box(s) in front of the software you wish to update and then click **Upgrade** button to start updating.

To Print Test Results

Vehicle test results stored in the SD card can be printed through computer.


1. Connect the scanner to the computer with the USB cable provided.
2. Launch the **FoxAssist** and log in with your Foxwell ID.
3. Click **Data Management** to view all the stored test results.
4. Choose the files you want to print and click **Print** button.

Powering up the scanner

Before using the scanner, make sure to provide power to the scanner.

The unit operates on any of the following sources:

12-volt vehicle power



USB connection to computer



Contact Us

For service and support, please contact us.

WebSite : www.foxwelltech.us
E-mail : support@foxwelltech.com
Service Number : + 86 - 755 - 26697229
Fax : + 86 - 755 - 26897226

REGISTER YOUR PRODUCT AT
http://www.foxwelltech.us/register.html

Pictures illustrated here are for reference only and this Quick Start Guide is subject to change without prior notice. For more detailed operations, please refer to the User's Manual.