
How to add SmartThings drivers for THIRDREALITY Smart Blind/Smart Button/Smart Switch/Contact Sensor/T&H Sensor/Multi-Function Night Light


1. Open this link in your PC browser. https://bestow-regional.api.smartthings.com/invite/adMKr50EXzj9

2. Log in your SmartThings Account.



4. Click “Enroll” --“Available Drivers” -- “Install” to install the device driver as needed.

   Install “Zigbee Switch” for Zigbee Multi-function Night Light.



- Name
  Zigbee Switch
- Description
  SmartThings driver for Zigbee switch devices
- Permissions
  - zigbee: Enable full access to Zigbee actions

  Install

- Name
  Zigbee Contact
- Description
  SmartThings driver for Zigbee contact devices
- Permissions
  - zigbee: Enable full access to Zigbee actions

  Install

- Name
  ThirdReality Humidity Sensor
- Description
  ThirdReality Temperature and Humidity sensor drivers
- Permissions
  - zigbee: Enable full access to Zigbee actions

  Install

5. Reboot your SmartThings hub by powering it off and power it on again.
6. “Scan for Nearby Devices” in SmartThings App to pair the THIRDRELAITY devices with your SmartThings hub.