

Smart Button



THIRD REALITY


Mounting Kit




AAA Battery x 2



Double-sided Tape



Magnet Sticker x 2




Icon Sticker x 9

LED Status


ZigBee Pairing: fast blinking in blue
Echo ZigBee pairing: fast blinking in blue and red
Off-line: slow blinking in red
Low power: double blinking in red

* To switch mode between standard ZigBee mode and Echo ZigBee mode by pressing the reset button for 5 times within 5 seconds.



Setting up your Smart Button

1. Follow instructions to set up your compatible ZigBee hub.
2. Slide the battery cover out (figure 1) and remove the battery insulation sheet.




3. The LED indicator flashes rapidly in blue, indicating that the Smart Button is in pairing mode by default.
   *If the Smart Button is not in paring mode, press and hold the reset button for 5 seconds (Figure 2) until the LED indicator flashes rapidly in blue, indicating that it is in pairing mode.
4. Configure the Smart Button with your ZigBee hub.
5. Close the Smart Button's battery cover.
6. After the pairing is completed, you can create routines in the corresponding smart home App or platform to control other connected devices.
   THIRDREALITY Smart Button supports three control settings: Pressed, Double Pressed and Held.

Install your Smart Button


We provide two different installation methods, place your Smart Button according to your requirement.

- Using the double-sided tape that included:



Double-sided Tape

- Using the magnet stickers that included:



Magnet Stickers

*Note: Smart Button is designed for indoor use only.

Pairing with Different Brands of Hubs


Before pairing, check for updates to make sure the firmware of the hub is up to date.

1. Pairing with Hubitat


Website: http://find.hubitat.com/


Pairing steps:

1) Remove the battery cover of the Smart Button, remove the battery insulation sheet, the LED indicator flashes quickly in blue, indicating the Smart Button is in pairing mode.
2) Visit your Hubitat Elevation hub device page from your web browser, select the Devices menu item from the sidebar, then select Discover Devices in the upper right.




3) Click Start ZigBee Pairing button after you select a ZigBee device type, the Start ZigBee Pairing button will put the hub into ZigBee pairing mode for 60 seconds.






4) After being paired successfully, it will be showed on page as on page as "ThirdReality Smart Button", you can rename it if needed, then tap "save".




5) Now you can see the Smart Button on the Devices page.




2. Pairing with Home Assistant through ZHA


Pairing steps:

1) Remove the battery cover of the Smart Button, remove the battery insulation sheet, the LED indicator flashes quickly in blue, indicating the Smart Button is in pairing mode.
2) Make sure Home Assistant Integrations ZigBee Home Automation Setup is ready, then go to "Configuration" page, click "integration".




3) Then click the "Devices" on the ZigBee item, the click "Add Devices".







4) After the pairing is successful, it will show as "Third Reality, Inc 3RSB22BZ" on the page.




5) Back to "Devices" page, then you can find the Smart Button added before. Click to enter in the control interface to set the Smart Button.



6) Click the "+" belongs to Automation and then you can add different actions to Third Reality Smart Button.





3. Pairing with Third Reality


ZigBee Hub Prepare: Third Reality Smart Hub
App: Third Reality App

Pairing steps:


1) Remove the battery cover of the Smart Button, remove the battery insulation sheet, the LED indicator flashes quickly in blue, indicating the Smart Button is in pairing mode.
2) Open Third Reality App, go to device page, tap "+" belongs to the Hub, choose "Smart Button" , then click "Pair".








3) After the pairing is completed, tap "Complete", then back to main interface




4) Tap "Smart Button" icon on device page, you can see the details, such as Battery, History Records etc. Then click Pressed / Double Pressed / Held, you can create different scenes.











5) Or you can enable Third Reality SkillX to Alexa, follow the prompts and tap "DISCOVER DEVICES" in Alexa app, it will be recognized as 3 motion sensors as "Button 1 Click", "Button 1 Double Click" and "Button 1 Long Click", then you can create routines to control other devices with the Smart Button.








SEARCH
Search
third reality
3
568 Results
Sort: Relevance
Third Reality Gadgets
"Alexa, ask third reality to change the clock format"
Smart Home
97
ThirdReality
"Alexa, turn off my switch"
Smart Home
11
Your Third Act
"Alexa, launch Third Act"
Lifestyle
11
Tom's Reality
"Alexa ask Tom's reality if it is cold"
Novelty & Humor
Home
Communicate
Play
Devices
More



THIRDREALITY
ThirdReality
3reality.com
Rated: Guidance Suggested
11
4
ENABLE TO USE
Account linking required
With the ThirdReality skill, smart home devices managed by ThirdReality App canbe controlled with Amazon Alexa.
Third Reality Home Solutions including Smart Switches, Smart LED Light Bulbs, and Zigbee hub provides a perfe...
See More
Start By Saying
English (US)
"Alexa, turn on my switch"
"Alexa, turn off my switch"
About
Note
Smart Home. This skill may share device
Home
Communicate
Play
Devices
More



Enable Third Reality Smart Home
cloud.3reality.com
Link your Third Reality account
zj01
....
5
Sign in
forget password? create an account.


ThirdReality Skill is Now Linked • now
Your Amazon account has been linked w
Your ThirdReality account has been successfully linked.
What to do next:
Close this window to discover smart-home devices you can control with Alexa.
6
CLOSE


Alexa is looking for devices to connect...
This may take up to 45 seconds
7


SETUP
3 devices found and connected
These devices have been added to your Alexa account. Next, continue setting up each of these devices one at a time.
8
NEXT


SETUP
Choose which connected device to set up first
You can delete connected devices anytime from the device settings page
NEW CONNECTED DEVICES
Button 1 Double Click
9
Button 1 Long Click
Button 1 Click
10
SET UP DEVICE


SETTINGS
Button 1 Click
Edit Name
ABOUT
Connected Via
ThirdReality
Description
Button of ThirdReality
Type
Motion sensor
11
Enabled
Home
Communicate
Play
Devices
More


Pairing with Amazon Echo


App: Amazon Alexa App


Pairing with Echo devices with built-in ZigBee hubs such As Echo V4, Echo Plus V1 & V2, Echo Studio, Echo Show 10（Gen2 & Gen3）, and Eero 6 & 6 pro.


1) Ask Alexa to check for updates before pairing.
2) Remove the battery cover of the Smart Button, remove the battery insulation sheet and install the batteries, the LED indicator blinks quickly in blue. The Smart Button is in standard ZigBee pairing mode.
3) To switch mode between standard ZigBee mode and Echo ZigBee mode by pressing the reset button for 5 times within 5 seconds.


4) Ask Alexa to discover devices, or open Alexa App, go to device page, tap "+" on top right, choose "Add Device", scroll down to the bottom and tap "other", tap "DISCOVER DEVICES", the Smart Button will be paired with your Echo device in a few seconds, it is recognized as a motion sensor.










SETUP
Connect your device to Alexa
First, make sure you set up your device according to the manufacturer's instructions.
Some devices need a skill to connect to Alexa. Check the skill store to see if you need a skill to use your device.
Some devices need a Zigbee hub or an Echo with a built-in hub to connect to Alexa. Check your device's instructions to see if it needs a hub. Connect your hub here.
When you discover devices, Alexa may connect additional compatible devices in your home. You can learn about or delete these devices in device settings.
DISCOVER DEVICES
4



SETUP
First motion sensor is set up and ready to use
DONE


5) Tap "First Motion Sensor" in all devices list to open the Smart Button device page, you can create routines with it to control other devices.
   * Please be aware of that since Alexa sees Smart Button as a motion sensor which has a cool down time of 30 seconds, in this case Smart Button can be triggered only once within 30 seconds.
   * Please make sure you create 2 same routines for both "motion detected" and "motion not detected", in order to avoid routine conflict.








FIRST MOTION SENSOR
Next
When Motion is...
Not Detected
Detected
When First motion sensor detects motion
Home
Communicate
Play
Devices
More


Cancel
NEW ROUTINE
Save
NAME
First motion sensor detects motion
Change
WHEN
First motion sensor detects motion
View/Edit
Anytime
Change
Add action
ex. Play weather
Home
Communicate
Play
Devices
More

FAQ

1) **How to factory reset the Smart Button?**

   Remove the back cover of the Smart Button, press and hold the reset button on the back for 3 seconds, the LED indicator will flashes quickly, now it has been factory reset and in pairing mode.

2) **How to change between 2 ZigBee pairing modes?**

   To switch mode between standard ZigBee mode and Echo ZigBee mode by pressing the reset button for 5 times within 5 seconds. When the LED indicator blinks quickly in blue and red, it is in ZigBee pairing mode for Echo devices. When the LED indicator blinks quickly in blue, it is in ZigBee pairing mode for other ZigBee hubs like SmartThings Hub etc..

3) When powered up,my smart button turns blue/red blinking

   - Your smart button is currently in pairing mode for Amazon Echo devices with built-in Zigbee hub.
   - If you want to use it with Third Reality smart hub/bridge, SmartThings, Hubitat, Home Assistant, or other hubs, follow these steps:
     - Quickly press the reset button on your smart button five times.
     - The LED light should start blinking blue. This means it's now in standard pairing mode and ready to connect with your preferred hub.

4) **How to setup the smart button in Alexa?**

- For Echo with NO built-in Zigbee hub: Echo Dot, Echo Show 15 etc.
  - Download and install the Third Reality app on your phone- Sign up/sign in your Third Reality account.
  - Connect the Third Reality Smart Hub to your 2.4GHz Wi-Fi network following the app's instructions.
  - Set up the Third Reality smart hub in the Third Reality app.
  - Long press the reset button of the smart button until the LED turns blue blinking.
  - Tap + and follow the on-screen instruction to pair the smart button with the Third Reality hub.
  - Navigate to the Skills & Games section, search for "Third Reality" and enable Third Reality Skill in your Alexa app, the smart button will be added automatically through account linking as 3 motion sensors: Button 1 Click, Button Double Click, Button Long Click.
- Using the Smart Button with Alexa.
  - Asingle press will register Button 1 Click "Motion detected" in the Alexa app.
  - A double press will register Button Double Click "Motion detected" in the Alexa app.
  - Holding the button will register Button Long Click "Motion detected" in the Alexa app.

- For Echo with built-in Zigbee hub: the 4th Gen Echo, Echo Plus, Echo Studio, 3rd Gen Echo Show 8, and the 2nd– and 3rd gen Echo Show 10, Echo Hub etc. While Alexa doesn't directly support smart buttons, you can still set it up as a contact sensor.
- Remove the battery cover and install the battery, the LED light should turn fast blinking in blue, quickly press the reset button for 5 times, the LED light should blink blue and red, indicating Echo pairing mode.
- Add the device in the Alexa app:
  - Open the Alexa app and tap the "+" button.
  - Scroll down and select "Other."
  - Alternatively, you can say "Alexa, discover devices."
  - Alexa will search for the button and add it as a contact sensor.
- Using the Smart Button with Alexa:
  - Asingle press will register as "Open" in the Alexa app.
  - Adouble press will register as "Closed."
  - Holding the button will toggle between "Open" and "Closed."

5) **Why does my smart button sometimes become unresponsive or even go offline?**

- Place the smart button next to the smart hub / bridge / smart speaker during pairing or software OTA update. Place the smart button within 12 meters from the Zigbee hub. Avoid mounting on metal surface which may lead to poor Zigbee connection.
- There are some common factors that can affect Zigbee connections, please try a few things for general Zigbee troubleshooting:
  - Make sure no battery level issue for the Zigbee device.
  - Place the Zigbee device near the Zigbee hub/smart bridge or the Zigbee repeater(Zigbee smart plug etc.), we suggest no more than 12 meters in open space.
  - Avoid metal surfaces when mounting the Zigbee devices.
  - Clear the area around your Zigbee hub: Move any wireless devices like Wi-Fi routers, or other hubs at least a meter away from the hub. These devices can sometimes mess with Zigbee signals.
  - Check your Wi-Fi router settings: Some Wi-Fi routers can interfere with Zigbee signals if they're on the same channel. See if you can change your Wi-Fi router channel to a different one (maybe channel 1 or 6) and see if that helps.
  - Check your Zigbee hub manual for troubleshooting Zigbee connection issues.

6) **How to add the smart button to Apple Home?**

- Set up the Bridge:
  Add the Third Reality Smart Bridge MZ1 to your Apple Home according to the bridge's instructions. Your iPhone and Apple speaker should be on the same 2.4GHz Wi-Fi network.
- Put the smart button in Pairing Mode:
  Long press the reset button on your smart button to factory reset it. The button's LEDlight will start blinking blue to indicate pairing mode.
- Start Bridge Pairing:
  Short press the pinhole button on your Third Reality Smart Bridge MZ1 to initiate Zigbee pairing mode. The smart button and bridge should automatically pair.

7) **How to add the edge driver in SmartThings?**

- Open this link in your web browser and log in your SmartThings account.
  https://bestow-regional.api.smartthings.com/invite/adMKr50EXzj9
- Click “Enroll”--“Available Drivers”-- “Install” to install the device driver.

FCC regulatory conformance

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could
void the user’ s authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help important announcement.

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user’ s authority to operate the equipment.

RF Exposure

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.
This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Limited Warranty

For limited warranty, please visit **www.3reality.com/device-support**
For customer support, please contact us at **info@3reality.com** or visit **www.3reality.com**
For help and troubleshooting related to Amazon Alexa, visit the Alexa app.

CE