

How to Turn Off the Led Indicator?




Step 1: Remove the Presence Sensor from App



Step 2: Add the Presence Sensor into Zigbee Hub on App(Hold the Reset Button of Sensor for 5s to Go into Connecting Mode)



Step 3:There Will be An Update Notification after Reconnection--Update Your Sensor



Step 4: Turn Off the Indicator, There Will be No Blinking Annoyance