
Keypad

For tolviviov Alarm System

User Manual




Say hello to tolviviov Keypad



Connect your Keypad to your Alarm System

Connect your keypad:

- Tap **Accessories** at the bottom to set up the keypad.
- Tap Remotes, then tap + Add, then there will be followed by a beeping sound from the Base Station.
- Press and Hold the panic button on the keypad for 3 seconds. 1 beeping sound will be heard as a confirmation.





Security Modes

Panic button

Trigger a loud emergency alarm while you're at home.

➢ **Press and hold the button for 3 seconds.**



Home Mode

Some sensors are monitored. Freedom and security, mixed.

➢ **Press and hold the button for 3 seconds.**



Disarmed Mode

No sensors are monitored. Move freely through the house.

➢ **Press 4 digit passcode, and press Disarmed.**



Away Mode

Some sensors are monitored. Freedom and security, mixed.

➢ **Press and hold the button for 3 seconds.**

Passcode



Default User passcode: 0000

Default Admin passcode: 000000

Changing the User passcode:

➢Enter Admin passcode, press✓.

➢Enter 1 plus the new 4 digit User passcode, then press✓.

Example: change the passcode to 1234.

Press 000000 + ✓, then press 1 + 1234 + ✓.

Changing the Admin passcode:

➢Enter Admin passcode, press ✓.

➢Enter 2 plus the new 6 digit Admin passcode, then press ✓.

Example: change the passcode to 123456.

Press 000000 + ✓, then press 2 + 123456 + ✓.

If you hear 1 long beeping with blue light on for 3 seconds, that means you have successfully change the passcode.

Reset the Keypad

Long press X and ✓for 5 seconds to reset the Keypad.