
Quick Start Guide

Model: H1370
Govee Ceiling Fan with Lights


English

In The Box



x 1

Ceiling Fan



x 1

Ceiling Bracket



x 1

User Manual



x 1

Quick Start Guide



x1

Service Card

Accessory Kit



x 4

Self-tapping Screw



x 4

Wire Nut (Optional)



x 4

1 to 1 Wire Connector




x 4

Plastic Screw Anchor

TOOLS NEEDED (NOT INCLUDED)

Essential Tools for a Successful Installation:




Ladder




Phillips Screwdriver

Before Installing



120 inches
from bottom edge
of blade to the floor



Please make sure that the holes in the ceiling are smaller than 5.4 inches.

Installing Your Device

Please read carefully and save these instructions before installing.


1. Unpack the box and check for all included items.
2. To prevent possible shock, turn off the main power at the circuit breaker before installing or fixing the device.
3. All electrical connections must be in accordance with local and National Electrical Code (N.E.C.) standards. If you are unfamiliar with proper electrical wiring connections, please consult a qualified electrician.

Installation work and electrical wiring must be done by qualified person(s) in accordance with all applicable codes and standards, including fire-rated construction.

Installing Ceiling Bracket


Step 1:

Remove two pre-installed screws and loosen another two pre-installed screws



Step 2:


Rotate to remove the bracket



Step 3:

Option 1


Use machine screws(provided with outlet box) when:
Securing to existing ceiling fan-rated outlet box.
Make sure it is securely installed and is acceptable for fan support of 15.9kg(35 lbs) or less.



Note: Machine screws are not included in the shipped package; they are typically provided with your outlet box.

Option 2

Use Woodscrews when:
Securing to support structure with approved electrical outlet box.




Woodscrews

Note: Make sure all four screws are installed to ensure safety and stability.

Connect the Wire


Step 1:

Hang the hooks on the back of the ceiling fan into the hook holes on the ceiling bracket.




Step 2:

a. Pull the orange locking buckles of the wire connector outwards to fully open them.



b. Make sure the wires are not tangled together before proceeding to the next step.



c. Connect the live wires from the ceiling and the light fixture to separate terminals on a wire connector.

d. Connect the neutral wires from the ceiling and the light fixture to separate terminals on a wire connector.

e. Connect the ground wires from the ceiling and the light fixture to separate terminals on a wire connector.


f. Place the cable and the connector in an appropriate location.

*Use the wire nuts when the wire can't be inserted into the connector.

This fan only requires three wires: live wire (black in the US, brown in the EU), neutral wire (white in the US, blue in the EU), and ground wire (yellow-green).

If your ceiling box has four or more wires, it is recommended to confirm the wiring with a qualified electrician. Any unused extra wires should be capped separately with wire connectors or wire nuts.


Any unused extra wires should be capped separately with wire connectors or wire nuts.



Installing Ceiling Fan


Step 1:

Rotate the fan clockwise to fix it onto the ceiling bracket.



Step 2:

Re-tighten the two screws that were previously removed and tighten the last two loosed screws.



Govee Home App

For FAQs and more information,
please visit: www.govee.com