# iQ MiniOven™




## Safety Guide

Cook smarter with CHEF iQ

## IMPORTANT SAFEGUARDS

Basic safety precautions should always be followed, including:

READ ALL THE INSTRUCTIONS

1. Do not touch hot surfaces. Use handles.
2. To protect against electric shock do not immerse cord, plugs, or unit body in water or other liquid.
3. Close supervision is necessary when any appliance is used by or near children.
4. Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
5. Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner. Contact CHEF iQ for examination, repair, or adjustment.
6. The use of accessory attachments not recommended by CHEF iQ may cause injuries.
7. Do not use outdoors.
8. Do not let cord hang over edge of table or counter or touch hot surfaces.
9. Do not place on or near a hot gas or electric burner, or in a heated oven.
10. Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
11. To disconnect, turn any control to OFF, then remove plug from wall outlet.
12. Do not use appliance for other than intended use.
13. Oversize foods or metal utensils must not be inserted into the oven, as they may create a fire or risk of electric shock.
14. A fire may occur if the oven is covered or touching flammable material, including curtains, draperies, walls, and the like, when in operation. Do not store any item on top of the appliance when in operation.
15. Do not clean with metal scouring pads. Pieces can break off the pad and touch electrical parts involving a risk of electric shock.
16. Extreme caution should be exercised when using containers constructed of materials other than metal or glass.
17. Do not store any items, other than manufacturer recommended accessories, in the oven when not in use.
18. Do not place any of the following items in the oven: paper, cardboard, plastic, etc.
19. Do not cover crumb tray or any part of the oven with metal foil. This will cause overheating of the oven.



California Proposition 65: (Applicable to California residents only.)

WARNING: Cancer and Reproductive Harm – www.P65Warnings.ca.gov.

HOUSEHOLD USE ONLY

SAVE THESE INSTRUCTIONS

## FCC STATEMENT

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

CAUTION

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

1. Reorient or relocate the receiving antenna.
2. Increase the separation between the equipment and the receiver.
3. Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
4. Consult the dealer or an experienced radio/TV technician for help.

To satisfy RF exposure requirements, a separation distance of 20 cm or more should be maintained between the antenna of this device and persons during device operation. To ensure compliance, operation at closer than this distance is not recommended.

## ISED REGULATORY COMPLIANCE

This device contains license-exempt transmitter(s)/ receiver(s) that comply with Innovation, Science and Economic Development Canada's license-exempt RSS(s). Operation is subject to the following two conditions:

1. This device may not cause interference.
2. This device must accept any interference, including interference that may cause undesired operation of the device.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

1. L'appareil ne doit pas produire de brouillage.
2. L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

This equipment complies with IC RSS-102 radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20 cm between the radiator and your body.

Cet équipement est conforme aux limites d'exposition aux radiations IC CNR-102 établies pour un environnement non contrôlé. Cet équipement doit être installé et utilisé avec une distance minimale de 20 cm entre le radiateur et votre corps.

## TERMS AND CONDITIONS

### Limited Warranty

RJ Brands, LLC d/b/a CHEF iQ® offers a limited 1-Year Warranty (the "Warranty") available on sales through authorized distributors and retailers only. Please note that this Warranty becomes valid from the date that you connect your product with the CHEF iQ App. To activate your warranty, follow these steps:

1. Download the CHEF iQ App from the App Store or Google Play.
2. Connect your CHEF iQ product to the app.

In cases where there is no connection, CHEF iQ requires a proof of purchase to include receipt, order confirmation, etc. at the discretion of the CHEF iQ Support Team. Please retain your proof of purchase even after registering. In the event that you do not have proof of your purchase date, we may declare your Warranty void, or we may, at our sole discretion, apply the date of manufacture as the purchase date for purposes of this Warranty.

The Warranty is nontransferable, applies only to the original purchaser, supersedes all other warranties, and constitutes the entire agreement between the consumer and CHEF iQ. Any changes to the Terms and Conditions of this Warranty must be in writing, signed by a representative of CHEF iQ. No other party has the right or ability to alter or change the Terms and Conditions of this Warranty.

## WHAT THE WARRANTY COVERS

### Manufacturer Defects

CHEF iQ products are warranted against defects in material and workmanship, under normal household use, for a period of 1 year from the date the Warranty is activated in accordance with the directions listed in the CHEF iQ User Guide. If your product does not work as it should, please contact Customer Support at support@chefiq.com so that we may assist you. We may ask you to please submit, via email, photos and/or video of the issue you are experiencing. This is to help us better assess the matter and possibly offer a quick fix. Photos and/or video may also be required to determine Warranty eligibility.

If the product is damaged, does not work as it should, or is no longer available, a replacement product of equal or lesser value will be sent at the discretion of the CHEF iQ Support Team. We reserve sole discretion whether to require you to return the purchased product to us prior to shipping you a replacement.

## THIS WARRANTY DOES NOT COVER

### Misuse

Damage that occurs from neglectful or improper use of products, including, but not limited to, damage that occurs as a result of usage with incompatible voltage, regardless of whether the product was used with a converter or adapter. See Safety Instructions in the CHEF iQ User Guide for information on proper use of product.

### Poor Maintenance

General lack of proper care. Please see Cleaning and Maintenance directions in the CHEF iQ User Guide for information on proper maintenance.

### Commercial Use

Damage that occurs from commercial use.

### Normal Wear and Tear

Damage or degradation expected to occur due to normal use over time.

### Altered Products

Damage that occurs from alterations or modifications by any entity other than CHEF iQ ; removal of the rating label affixed to the product.

### Catastrophic Events

Damage that occurs from fire, floods, or natural disasters.

### Loss of Interest/Buyer's Remorse

Claims of loss of interest or enjoyment.

## HAVE A QUESTION?

Please reach out to us at chefiq.com/support.

Need more help? We're here for you! Contact us at support@chefiq.com or (888) 593-1701.

## OTHER LIMITATIONS:

ALL WARRANTIES OF ANY KIND WHATSOEVER, EXPRESS, IMPLIED AND STATUTORY, ARE HEREBY DISCLAIMED. ALL IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE HEREBY DISCLAIMED, PROVIDED THAT IF ANY IMPLIED WARRANTY OF ANY KIND IS REQUIRED BY ANY JURISDICTION, INCLUDING MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, THE DURATION OF SUCH IMPOSED IMPLIED WARRANTY IS LIMITED TO ONE (1) YEAR. EXCEPT WHERE SUCH LIABILITY IS REQUIRED BY LAW, THIS WARRANTY DOES NOT COVER, AND CHEF iQ SHALL NOT BE LIABLE FOR, INCIDENTAL, INDIRECT, SPECIAL, OR CONSEQUENTIAL DAMAGES, INCLUDING WITHOUT LIMITATION, DAMAGE TO, OR LOSS OF USE OF THE PRODUCT, OR LOST SALES OR PROFITS OR DELAY OR FAILURE TO PERFORM THIS WARRANTY OBLIGATION. THE REMEDIES PROVIDED HEREIN ARE THE EXCLUSIVE REMEDIES UNDER THIS WARRANTY, WHETHER BASED ON CONTRACT, TORT, OR OTHERWISE.

CHEF iQ® is a registered trademark of RJ Brands, LLC.

iQ MiniOven™ is a trademark of RJ Brands, LLC.

CHEF iQ

CQ505G110824