Mini Aigital WiFi Router

2 Working Mode:


a. **Repeater Mode:**Used to extend existing wifi to longer range, achieve signal full coverage.

b. Router Mode: Used as a wifi router, create wireless and wired network for devices.


How to set up the Repeater Mode:

A.Plug device into socket. Wait for about 1 minute to establish a signal till you see the WLAN led blinking stably.


B.On your phone/laptop connect with wifi name called"Wifi-XXXXXX" (XXXXXX is the last 6 letters of the MAC address)



C. Go to 192.168.188.1 on your browser (on the address bar)




D. Log in. Username and password are "admin"




E. Click on "Extender Mode"


F. Select your home wifi and click "Scan"



G. Enter your home wifi password, Set a new SSID(name) and a new password, click "Apply".



H. Close the page and connect with the new wifi you set. Enjoying!



Contact us:If you have any questions or problems when using,please feel free to contact us by Amazon message or send mail to amazonsupport@aigital.cn . We will respond to your issue within 24 hours.

Aigital-Store is committed to providing each customer with the highest standard of customer service.

Everyday is a lucky day.

Dear.Goodnight.