
Quick Start Guide


Battery-powered use:

Step1




Align the inflation tube screw with the air outlet and tighten it clockwise.

Step2




Press and hold the power button for 2 seconds to turn on

Step3




Affix the nozzle to the tire valve.

Step4



Select the desired mode and air pressure.

Step5



Press the power button once to start inflating


Step6

After the inflation is completed, the device will automatically stop.

Powered by DC cigarette lighter:


When the battery runs out and you just forget to charge it.

Step1




Align the inflation tube screw with the air outlet and tighten it clockwise.

Step2




Connect the 12V plug to the socket on the top of the machine.

Step3



Insert the larger end of the plug into the car's 12V power socket.


Step4



Affix the nozzle to the tire valve.

Step5

Select the desired mode and set the desired air pressure, press the power button to start inflating



Quick Start Guide

How to inflate your bike

The first thing to determine if your bike is a French valve, the following picture will tell the difference：

Presta valve




Schrader valve



If it's an schrader valve, you can follow step 3 to inflate it directly using an air hose.


If it's a French bike valve, you can follow these steps to inflate it:

Step1



Turn the top of the Presta valve counterclockwise to loosen .

Step2



Rotate the included Presta valve converter clockwise into the bicycle valve.

Step3



Finally, connect the air tube to the bicycle valve to start inflation.

Step4

Once inflation is complete, remove the Presta bike converter and turn the valve clockwise to lock it.



Quick Start Guide

For any questions, please contact us
Email: support@aborderproducts.com