tp-link | Wi-Fi 7

Quick Installation Guide

Wi-Fi 7 High Gain
Wireless USB Adapter

Images are for demonstration only.

©2024 TP-Link 7106511433 REV1.1.0


Before You Start:

- Make sure your Router or Access Point supports **the Wi-Fi 7 standard**.
- It is recommended to use the adapter on Windows 11 (64-bit) or above.

1 Connect to a Computer


Note: It is recommended to connect the adapter to a USB 3.0 (SS) port.

Option 1: Directly



Option 2: Via the USB Extension Cable

Note: For optimal performance, it is recommended to use the provided USB extension cable.



2 Install Driver

a. Go to **My Computer** or **This PC**.

b. Double-click the **TP-Link** CD-ROM then run **SetupInstall.exe** to install driver.




Notes:

- If you cannot find the setup program, please download the driver at www.tp-link.com/support. You can also check for new releases and download the latest drivers on this website.
- If an unknown publisher message pops up, select **Yes** to continue.
- If Windows User Account Control requires admin credentials, type user name and password of your Windows administrator account.

3 Join a Wireless Network

a. Click the network icon on the taskbar (the icon might look like one of these: , , , or).

b. Select your Wi-Fi network, click **Connect** and enter the password when prompted.



Troubleshooting

If you have problems during the installation, please refer to the following online FAQs.

T1. Can't find the hardware version of the adapter:
https://www.tp-link.com/faq-46.html

T2. Can't find or connect to the wireless networks:
https://www.tp-link.com/faq-2253.html

T3. Can't install the driver:
https://www.tp-link.com/faq-2252.html

Support

For technical support, replacement services, user guides, and other information, please visit **https://www.tp-link.com/support**, or simply scan the QR code.

- Do not attempt to disassemble, repair, or modify the device. If you need service, please contact us.
- Do not use the device where wireless devices are not allowed.
- Keep the device away from water, fire, humidity or hot environments.
- This equipment can be powered only by equipments that comply with Power Source Class 2 (PS2) or Limited Power Source(LPS) defined in the standard of IEC 62368-1.

TP-Link hereby declares that the device is in compliance with the essential requirements and other relevant provisions of directives 2014/53/EU, 2011/65/EU and (EU) 2015/863.
The original EU Declaration of Conformity may be found at https://www.tp-link.com/en/support/ce

TP-Link hereby declares that the device is in compliance with the essential requirements and other relevant provisions of the Radio Equipment Regulations 2017.
The original UK Declaration of Conformity may be found at https://www.tp-link.com/support/ukca