
USB Type-C to 10G Ethernet Adapter - USB4 and Thunderbolt 3 Compatible


Product ID

USB4-10GBE-ETHERNET

Front View



Rear View



**Product may vary from image*

	Feature	Function
1	Host Connection	• Connect to a **USB4** or **Thunderbolt** compatible **Host Computer**
2	LED Indicator	• **Solid Green** = Indicates that the **USB4 Network Adapter** is connected to the **Host Computer**

3	Ethernet Port & LED Indicators	• Connect an **Ethernet Cable**
		Use Cat6 or better cabling for 10 Gbps speeds
		• **Left LED Indicator** is **Link Speed**
		  • **Solid Green** = 10 Gbps
		  • **Solid Orange** = 5 Gbps/2.5 Gbps/1 Gbps/100 Mbps
		• **Right LED Indicator** is **Link Status**
		  • **Solid Green** = Active link
		  • **Flashing Green** = Activity

Package Contents

- USB4 Network Adapter x 1
- 20 in (50 cm) USB4 Cable x 1
- Quick-Start Guide x 1

Requirements

For the latest manuals, product information, technical specifications, and declarations of conformance, please visit: www.StarTech.com/USB4-10GBE-ETHERNET

- USB4 or Thunderbolt compatible host computer
- Ethernet Cable (Cat6 or better)

Installation

USB4 Host

1. Connect the included **USB4 Cable** from a **USB4 port** on the **Host Computer** to the **Host Connection** on the front of the **USB4 Network Adapter**.
2. Connect an **Ethernet Cable** from the **Ethernet Port** on the back of the **USB4 Network Adapter** to a **Network Port** or **Device**.

Install the Driver

Note: *For the latest list of supported operating systems, please visit:* www.StarTech.com/USB4-10GBE-ETHERNET

1. Navigate to www.StarTech.com/USB4-10GBE-ETHERNET
2. Click the **Drivers & Downloads** tab.
3. Under **Driver(s)**, download the **Driver** for your operating system.

For Windows Systems


a. Extract the contents of the **Driver Package** by **Right Clicking** the **Driver Folder** that was downloaded from the website and select **Extract All**. Follow the on-screen instructions to finish the **Extraction**.

b. Follow the instructions on the accompanying PDF file for further **Installation Instructions.**

For Linux Systems

a. Extract the contents of the **Driver Package.**

b. Follow the instructions on the accompanying **README.txt** file.



HQ Contact:
StarTech.com Ltd.
45 Artisans Crescent,
London, ON N5V 5E9,
Canada

US Contact:
StarTech.com USA LLP
4490 South Hamilton Rd,
Groveport, OH 43125,
United States

UK Contact:
StarTech.com Ltd.
15 Gowerton Rd,
Northampton, NN4 7BW,
United Kingdom

EU Contact:
StarTech.com Ltd.
Siriusdreef 17-27
2132 WT Hoofddorp
The Netherlands

JP Contact:
StarTech.com K.K.
Atelier Yours Ogawamachi 7F
1-10-2 Kanda Ogawamachi
Chiyoda-ku, Tokyo 101-0052
Japan

FR: startech.com/fr
DE: startech.com/de
ES: startech.com/es
NL: startech.com/nl
IT: startech.com/it
JP: startech.com/jp